

Contents

Motorcycle Safety P. 2

Operation Guide P. 18

Maintenance P. 56

Troubleshooting P. 102

Information P. 124

Specifications P. 147

Index P. 151

Welcome

Congratulations on your purchase of a new Honda motorcycle. Your selection of a Honda makes you part of a worldwide family of satisfied customers who appreciate Honda's reputation for building quality into every product.

To ensure your safety and riding pleasure:

- Read this owner's manual carefully.
- Follow all recommendations and procedures contained in this manual.
- Pay close attention to safety messages contained in this manual and on the motorcycle.

To protect your investment, we urge you to take responsibility for keeping your motorcycle well serviced and maintained. Also, observe the break-in guidelines, and always perform the pre-ride inspection and other periodic checks in this manual.

When service is required, remember that your Honda dealer knows your motorcycle best. If you have the required mechanical "know-how" and tools, you can purchase an official Honda Service Manual to help you perform many maintenance and repair tasks. ≥ P. 141

Read the warranty information thoroughly so that you understand the warranty coverage and that you are aware of your rights and responsibilities. ≥ P. 142

You may also want to visit our website at www.powersports.honda.com.

Canada www.honda.ca

Happy riding!

California Proposition 65 Warning

WARNING: This product contains or emits chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

A Few Words About Safety

Your safety, and the safety of others, is very important. Operating this motorcycle safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on safety labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all hazards associated with operating or maintaining a motorcycle. You must use your own good judgment.

You will find important safety information in a variety of forms, including:

- Safety labels on the motorcycle
- Safety Messages preceded by a safety alert symbol and one of three signal words: DANGER, WARNING, or CAUTION. These signal words mean:

3 DANGER

You **WILL** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

3 WARNING

You **CAN** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

3 CAUTION

You **CAN** be **HURT** if you don't follow instructions.

Other important information is provided under the following titles:

NOTICE Information to help you avoid damage to your motorcycle, other property, or the environment.

Motorcycle Safety

This section contains important information for safe riding of your motorcycle.
Please read this section carefully.

Safety Guidelines	P. 3
Safety Labels	P. 7
Safety Precautions	P. 9
Riding Precautions	P. 10
Accessories & Modifications	P. 15
Loading	P. 16

Safety Guidelines

Follow these guidelines to enhance your safety:

- Perform all routine and regular inspections specified in this manual.
- Stop the engine and keep sparks and flame away before filling the fuel tank.
- Do not run the engine in enclosed or partly enclosed areas. Carbon monoxide in exhaust gases is toxic and can kill you.

Always Wear a Helmet

It's a proven fact: helmets and protective apparel significantly reduce the number and severity of head and other injuries. So always wear an approved motorcycle helmet and protective apparel. 2 P. 9

Before Riding

Make sure that you are physically fit, mentally focused and free of alcohol and drugs. Check that you and your passenger are both wearing an approved motorcycle helmet and protective apparel. Instruct your passenger on holding onto the grab rails or your waist, leaning with you in turns, and keeping their feet on the footpegs, even when the motorcycle is stopped.

Take Time to Learn & Practice

Even if you have ridden other motorcycles, practice riding in a safe area to become familiar with how this motorcycle works and handles, and to become accustomed to the motorcycle's size and weight.

Safety Guidelines

We recommend that all riders take a certified course approved by the Motorcycle Safety Foundation (MSF). New riders should start with the basic course, and even experienced riders will find the advanced course beneficial. For information about the MSF training course nearest you, call the national toll-free number: (800) 446-9227.

USA Other riding tips can be found in the You and Your Motorcycle Riding Tips booklet that came with your motorcycle.

Ride Defensively

Always pay attention to other vehicles around you, and do not assume that other drivers see you. Be prepared to stop quickly or perform an evasive maneuver.

Make Yourself Easy to See

Make yourself more visible, especially at night, by wearing bright reflective clothing, positioning yourself so other drivers can see you, signaling before turning or changing lanes, and using your horn when necessary.

Ride within Your Limits

Never ride beyond your personal abilities or faster than conditions warrant. Fatigue and inattention can impair your ability to use good judgment and ride safely.

Don't Drink and Ride

Alcohol and riding don't mix. Even one alcoholic drink can reduce your ability to respond to changing conditions, and your reaction time gets worse with every additional drink. Don't drink and ride, and don't let your friends drink and ride either.

Keep Your Honda in Safe Condition

It's important to keep your motorcycle properly maintained and in safe riding condition. Inspect your motorcycle before every ride and perform all recommended maintenance. Never exceed load limits (2 P. 16), and do not modify your motorcycle or install accessories that would make your motorcycle unsafe (2 P. 15).

If You are Involved in a Crash


Personal safety is your first priority. If you or anyone else has been injured, take time to assess the severity of the injuries and whether it is safe to continue riding. Call for emergency assistance if needed. Also follow applicable laws and regulations if another person or vehicle is involved in the crash.

If you decide to continue riding, first turn the ignition switch off, and evaluate the condition of your motorcycle. Inspect for fluid leaks,

check the tightness of critical nuts and bolts, and check the handlebar, control levers, brakes, and wheels. Ride slowly and cautiously. Your motorcycle may have suffered damage that is not immediately apparent. Have your motorcycle thoroughly checked at a qualified service facility as soon as possible.

Emergency Shut-down Procedure for Motorcycles Equipped with Dual Clutch Transmission

VFR1200XD/XDA

Unlike standard motorcycles, or its manual transmission sibling, the VFR1200XD/XDA with dual-clutch transmission does not have a clutch lever that would provide you with an additional means to control the engine power being transmitted to the rear wheel. Thus, in the unlikely event that you experience a stuck throttle or other unintended application of power to the rear wheel, you should shut down the engine by use of the engine stop switch (2 P. 32). By moving this switch to the  (Off) position, you will immediately stop the engine but maintain all electrical system functions, including lights and indicators.

Carbon Monoxide Hazard

Exhaust contains poisonous carbon monoxide, a colorless, odorless gas. Breathing carbon monoxide can cause loss of consciousness and may lead to death.

If you run the engine in confined or even partly enclosed area, the air you breathe could contain a dangerous amount of carbon monoxide. Never run your motorcycle inside a garage or other enclosure.

3 WARNING

Carbon monoxide gas is toxic.
Breathing it can cause
unconsciousness and even kill you.

Avoid any areas or activities that
expose you to carbon monoxide.

Safety Labels

Safety and information labels on your motorcycle provide important safety information and may warn you of potential

hazards that could cause serious injury. Read these labels carefully and don't remove them. If a label comes off or becomes hard to read, contact your dealer for a replacement.

⚠ WARNING

Improper loading can cause a crash and you may be seriously hurt or killed. See "Load Limits and Guidelines" in your Owner's Manual for complete instructions.

For your protection, always wear your helmet while riding. Read the owner's manual carefully.


108
DANGER

อันตราย
BAHAYA NGUY HIEM

- ▶ NEVER OPEN WHEN HOT.
- ▶ ห้ามเปิดเวลา ร้อน
- ▶ JANGAN BUKA BILA (SAAT) PANAS
- ▶ KHÔNG ĐƯỢC MỞ KHÍ MÁY NÓNG

T2T

TIRE INFORMATION		
Cold tire pressures : (Up to maximum weight capacity)		
Front	250kPa 2,50kgf/cm ² 36psi	
Rear	290kPa 2,90kgf/cm ² 42psi	
(Up to 90kg(200lbs) load)		
Front	250kPa 2,50kgf/cm ² 36psi	
Rear	290kPa 2,90kgf/cm ² 42psi	
Maximum weight capacity :180kg(397lbs)		
Tire size : Front 110/80R19M/C 59V		
Rear 150/70R17M/C 69V		
Tire brand	Front	Rear
PIRELLI	SCORPION TRAIL E	SCORPION TRAIL E
BRIDGESTONE	BW-501 RADIAL F	BW-502 RADIAL F
Min. recommend tire center tread depth.		
	Front 1,5mm(0,06in.)	Rear 2,0mm(0,08in.)
Read owner's manual.		
This motorcycle is equipped with tubeless tires.		



Max. weight limit
10kg / 22lbs

Safety Precautions

- Ride cautiously and keep your hands on the handlebar and feet on the footpegs.
- Keep passenger's hands onto the grab rails or your waist, passenger's feet on the footpegs while riding.
- Always consider the safety of your passenger, as well as other drivers and riders.

Protective Apparel

Make sure that you and any passenger are wearing an approved motorcycle helmet, eye protection, and high-visibility protective clothing. Ride defensively in response to weather and road conditions.

Helmet

Should be safety-standard certified, high-visibility, and correct size for your head

- Must fit comfortably but securely, with the chin strap fastened

- Face shield with unobstructed field of vision or other approved eye protection

USA Look for a DOT (Department of Transportation) certification label on any helmet you buy.

3 WARNING

Not wearing a helmet increases the chance of serious injury or death in a crash.

Make sure that you and any passenger always wear an approved helmet and protective apparel.

Gloves

Full-finger leather gloves with high abrasion resistance

Riding Precautions

Boots or Riding Shoes

Sturdy boots with non-slip soles and ankle protection

Jacket and Pants

Protective, highly visible, long-sleeved jacket and durable long pants for riding (or a protective suit).

Riding Precautions

Break-in Period

During the first 300 miles (500 km) of running, follow these guidelines to ensure your motorcycle's future reliability and performance.

- Avoid full-throttle starts and rapid acceleration.
- Avoid hard braking and rapid down-shifts.
- Ride conservatively.

Brakes

Observe the following guidelines:

- Avoid excessively hard braking and down-shifts.
 - ⌋ Sudden braking can reduce the motorcycle's stability.
 - ⌋ Where possible, reduce speed before turning; otherwise you risk sliding out.

- Exercise caution on low traction surfaces.
 - ⊣ The tires slip more easily on such surfaces and braking distances are longer.
- Avoid continuous braking.
 - ⊣ Repeated braking, such as when descending long, steep slopes can seriously overheat the brakes, reducing their effectiveness. Use engine braking with intermittent use of the brakes to reduce speed.
- For full braking effectiveness, operate both the front and rear brakes together.

■ Combined ABS

Your motorcycle's rear brake system is linked to the front brake. This means that operating the rear brake pedal applies the rear brake and a portion of the front brake.

Operating the front brake lever applies only the front brake.

For full braking effectiveness, operate both the front and rear brakes together.

This model is also equipped with an Anti-lock Brake System (ABS) designed to help prevent the brakes from locking up during hard braking.

- ABS does not reduce braking distance. In certain circumstances, ABS may result in a longer stopping distance.
- ABS does not function at speeds below 6 mph (10 km/h).
- The brake lever and pedal may recoil slightly when applying the brakes. This is normal.
- Always use the recommended tires to ensure correct ABS operation.

Riding Precautions

Engine Braking

Engine braking helps slow your motorcycle down when you release the throttle. For further slowing action, downshift to a lower gear. Use engine braking with intermittent use of the brakes to reduce speed when descending long, steep slopes.

Wet or Rainy Conditions

Road surfaces are slippery when wet, and wet brakes further reduce braking efficiency. Exercise extra caution when braking in wet conditions.

If the brakes get wet, apply the brakes while riding at low speed to help them dry.

Parking

- Park on a firm, level paved surface.
- If you must park on a slight incline or loose surface, park so that the motorcycle cannot move or fall over.
- Make sure that high-temperature parts cannot come into contact with flammable materials.
- Do not touch the engine, muffler, brakes and other high-temperature parts until they cool down.
- To reduce the likelihood of theft, always lock the handlebar and remove the key when leaving the motorcycle unattended. Use of an anti-theft device is also recommended.

■ Parking with the Side Stand or Center Stand

1. Stop the engine.

2. Using the side stand

Push the side stand down.

Slowly lean the motorcycle to the left until its weight rests on the side stand.

Using the center stand VFR1200XA/XDA

To lower the center stand, stand on the left side of the motorcycle. Hold the left handle grip and the left grab rail. Press down on the tip of the center stand with your right foot and, simultaneously, pull up and back.

3. Turn the handlebar fully to the left.

□ Turning the handlebar to the right reduces stability and may cause the motorcycle to fall.

4. Turn the ignition switch to the LOCK position and remove the key. ≥ P. 33

Refueling and Fuel Guidelines

Follow these guidelines to protect the engine and catalytic converter:

- Use only unleaded gasoline.
- Use recommended octane number. Using lower octane gasoline will result in decreased engine performance.
- Do not use fuels containing a high concentration of alcohol. ≥ P. 140
- Do not use stale or contaminated gasoline or an oil/gasoline mixture.
- Avoid getting dirt or water in the fuel tank.

Honda selectable torque control (Torque Control)

When the system detects rear wheel spin during acceleration, the system will limit the amount of torque applied to the rear wheel based on the Torque Control level selected.

Torque Control will allow some wheel spin during acceleration at the lower Torque Control levels settings. Select a level that is appropriate for your skill and riding conditions.

Torque Control does not work during deceleration and will not prevent the rear wheel from skidding due to engine braking. Do not close the throttle suddenly, especially when riding on slippery surfaces.

Torque Control may not compensate for rough road conditions or rapid throttle operation.

Always consider road and weather conditions, as well as your skills and condition, when applying throttle.

If your motorcycle gets stuck in mud, snow or sand, it may be easier to free it with the Torque Control temporarily switched off.

Temporarily turning off Torque Control also may help you maintain control and balance when riding on off-road terrain.

Always use the recommended tires to ensure correct Torque Control operation.

Accessories & Modifications

We strongly advise that you do not add any accessories that were not specifically designed or approved for your motorcycle by Honda or make modifications to your motorcycle from its original design. Doing so can make it unsafe. Modifying your motorcycle may also void your warranty and make your motorcycle illegal to operate on public roads and highways. Before deciding to install accessories on your motorcycle be certain the modification is safe and legal.

3 WARNING

Improper accessories or modifications can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding accessories and modifications.

Do not pull a trailer with, or attach a sidecar to, your motorcycle. Your motorcycle was not designed for these attachments, and their use can seriously impair your motorcycle's handling.

Loading


- Carrying extra weight affects your motorcycle's handling, braking and stability. Always ride at a safe speed for the load you are carrying.
- Avoid carrying an excessive load and keep within specified load limits.
 - ≥ **Maximum weight capacity/Maximum weight on rear carrier** P. 147
- Tie all luggage securely, evenly balanced and close to the center of the motorcycle.
- Do not place objects near the lights or the muffler.


3 WARNING

Overloading or improper loading can cause a crash and you can be seriously hurt or killed.


Follow all load limits and other loading guidelines in this manual.

Parts Location





Instruments



Tachometer red zone
(excessive engine rpm range)

Tachometer

NOTICE

Do not operate the engine in the tachometer red zone. Excessive engine speed can adversely affect engine life.

TOTAL/TRIP button


FCD button

TOTAL/TRIP button & **FCD** button

Press and hold both buttons to change the speed, mileage and fuel mileage units ("mph" & "mile" & "mile/gal" or "km/h" & "km" & "km/L") for the speedometer, odometer, and tripmeter, also to change the temperature ("°F" or "°C").

Press **FCD** button to select either "mph" & "mile" & "mile/gal" or "km/h" & "km" & "km/L", then press **TOTAL/TRIP** button to set.

Press **FCD** button to select either "°F" or "°C", then press **TOTAL/TRIP** button to set.



Torque Control level (P40)

Fuel gauge

Remaining fuel when only 1st (E) segment starts flashing:
approximately 1.06 US gal (4.0 liters)



At the same time, the available driving distance is displayed.

Handle grip heater status icon **VFR1200XA/XDA**

The handle grip heater status icon will appear while the handle grip heater is on. (P38)

Display Check

When the ignition switch is turned on, all the mode and digital segments will show. If any part of these displays does not come on when it should, have your dealer check for problems.

Instruments (Continued)



Clock (12-hour display)

To set the clock (P24)

Coolant temperature gauge ()

- Above 252 °F (122 °C):
 - High coolant temperature indicator lights
 - 5th (H) segment flashes
- Even if the engine coolant temperature is low, the cooling fan may start running when you rev up the engine. This is normal.

Backlight brightness adjustment (P25)

Odometer [TOTAL] & Tripmeter [TRIP A/B]

TOTAL/TRIP button switches between odometer & tripmeters.

- Odometer: Total distance ridden.
- Tripmeter: Distance ridden since tripmeter was reset (press and hold **TOTAL/TRIP** button to reset to 0.0 mile/km. At the same time reset the average fuel mileage).

Instruments *(Continued)*

To set the clock:

- !a Turn the ignition switch ON while pressing and holding the **FCD** button. The hour digits start flashing.



- !b Press **FCD** button until the desired hour is displayed.
 U Press and hold to advance the hour fast.



- !c Press **TOTAL/TRIP** button. The minute digits start flashing.



- !d Press **FCD** button until the desired minute is displayed.
 U Press and hold to advance the minute fast.




- !e Press **TOTAL/TRIP** button. The clock is set.
 U The time can also be set by turning the ignition switch OFF.
 The display will stop flashing automatically and the adjustment will be cancelled if the button is not pressed for about 30 seconds.

Backlight brightness adjustment:

You can adjust the brightness five levels.

!a Press and hold **TOTAL/TRIP** button when the display in the odometer. The brightness digits is indicated.

!b Press **FCD** button until the desired brightness is displayed.




!c Press **TOTAL/TRIP** button. The brightness is set.

U The brightness can also be set by turning the ignition switch off.


The adjustment will be cancelled if the button is not pressed for about 30 seconds.

Instruments (Continued)




Fuel mileage meter & Air temperature gauge

The current fuel mileage, average fuel mileage, air temperature and no indication can be selected by pressing the **FCD** button.



When the 1st (E) segment of the fuel gauge is flashed

Available driving distance is displayed. Then the amount of remaining fuel, current fuel mileage, average fuel mileage, air temperature gauge, no indication and available driving distance can be selected by pressing the **FCD** button.



Indication mode change of current fuel mileage and average fuel mileage

If the "km/h" for speed and "km" for mileage are selected, the fuel mileage can be switched to "km/L or L/100km".

Press and hold **FCD** button to switch between "km/h or L/100km".



Current fuel mileage

Current fuel mileage shows the current, or instant fuel mileage you are getting.

When your motorcycle speed is 3 mph (5 km/h) or below, " - . - " is displayed.

Average fuel mileage

The average fuel mileage is based on the each tripmeter A and tripmeter B. The average fuel mileage since tripmeter was reset. When " - . - " is displayed, see your dealer for service.

Average fuel mileage is also reset when the tripmeter is reset. (P23)

Air temperature gauge (AIR)

Display range: 14 to 122 °F (-10 to 50 °C)

- Below 15 °F (-11 °C): " - - " displays
 - Above 122 °F (50 °C): Air temperature gauge (flashing digits)
- ⓘ The temperature readout may be incorrect at low speeds due to reflected heat.

Instruments *(Continued)*

Available driving distance

When the 1st (E) segment of the fuel gauge is flashed (less than 1.0 US gal/4.0 liters), the estimated available driving distance is indicated. When the amount of remaining fuel becomes less than 0.2 US gal/1.0 liter, " - - " will be indicated. The indicated available driving distance is by calculation depending on the driving conditions, and the indicated figure may not always be the actual allowable distance. When the fuel gauge near to E or when E segment blinks, fill fuel promptly.



Remaining fuel

When the 1st (E) segment of the fuel gauge is flashed (less than 1.0 US gal/4.0 liters), the estimated amount of remaining fuel can be selected. When the amount of remaining fuel becomes less than 0.2 US gal/1.0 liter, " - . - " will be indicated. The amount of remaining fuel is calculated from the driving conditions. The indicated amount of remaining fuel may be different from the actual amount. When the fuel gauge near to E or when E segment blinks, fill fuel promptly.





S indicator VFR1200XD/XDA

Comes on when the S mode is selected in the AT MODE.
(P48)

D indicator VFR1200XD/XDA

Comes on when the D mode is selected in the AT MODE.
(P48)




Gear position indicator

VFR1200X/XA

The gear position is shown in the gear position indicator.

VFR1200XD/XDA

The gear position is shown in the gear position indicator when the D, S mode or MT MODE are selected.

- "-" appears for a few seconds and then goes off when the engine starts.
 - "-" flashes when the engine stop switch position is changed from  (Run) to  (Off) position with the ignition switch on.
 - "-" flashes when the ignition switch is turned on with the engine stop switch  (Off) position.
- The indicator may flash if:
- The front wheel leaves the ground.
 - You turn the wheel while the motorcycle is upright on the stand.

This is normal. To operate the system again, turn the ignition switch off, then on again.

If the "-" indicator is blinking in the gear position window while riding: (P108)

Indicators

If one of these indicators does not come on when it should, have your dealer check for problems.

Parking brake indicator VFR1200XD/XDA

Lights as a reminder that you have not released the parking brake lever. (P36)

Low oil pressure indicator

Comes on when the ignition switch is turned on.

Goes off when the engine starts.

If it comes on while engine is running: (P105)

ABS (Anti-lock Brake System) indicator


Comes on when the ignition switch is turned on. Goes off when your speed reaches approximately 6 mph (10 km/h).

If it comes on while riding: (P106)

High coolant temperature indicator


If it comes on while riding: (P104)

PGM-FI (Programmed Fuel Injection) malfunction indicator lamp (MIL)

Comes on briefly when the ignition switch is turned on with the engine stop switch in the  (Run) position.

If it comes on while engine is running: (P105)






- Comes on when the ignition switch is turned on. Goes off when your speed reaches approximately 6 mph (10 km/h) to indicate Torque Control is ready to work.
- Blinks when Torque Control is operating.

If it comes on while riding: (P107)



Switches

VFR1200X/XA



Horn button


Headlight dimmer switch


-  : High beam
-  : Low beam

Passing light control switch

Flashes the high beam headlight.

Engine stop switch

Should normally remain in the  (Run) position.

- ⌋ In an emergency, switch to the  (Off) position (the starter motor will not operate) to stop the engine.



Start button

Headlight turns off when operating the starter motor.



Hazard switch

Switchable when the ignition switch is on. Can be turned to off regardless of the ignition switch position.

- ⌋ The signals continue flashing with the ignition switch is OFF or LOCK after the hazard switch is on.

Ignition Switch



Switches the electrical system on/off, locks the steering.

- Key can be removed when in the OFF or LOCK position.

Steering Lock

Lock the steering when parking to help prevent theft.

A U-shaped wheel lock or similar device is also recommended.



Locking


- Turn the handlebar all the way to the left.
- Push the key down, and turn the ignition switch to the LOCK position.
 - Jiggle the handlebar if the lock is difficult to engage.
- Remove the key.

Unlocking

Insert the key, push it in, and turn the ignition switch to the OFF position.

Switches *(Continued)*

VFR1200X/XA



Turn signal switch

The turn signal will automatically stop when you complete the turn. (You can manually cancel the lights by pressing the switch in.)


When a lane change, the turn signal lights is automatically stopped in 7 seconds or after riding 131.2 yards (120 m).

In some cases, the timing at which the turn signal stops is changed.

Always use the recommended tires to ensure correct automatic cancellation operation.

Torque Control switch

Torque Control level setting and
Torque Control on/off. (P40)



Handle grip heater switch VFR1200XA/XDA

Change the handle grip heater level or turn the handle grip heater on and off. (P38)

Switches (Continued)

VFR1200XD/XDA

Parking brake lever and Release button

Be sure the parking brake is applied while parking and warming up the engine.

⌋ Make sure the parking brake lever is released before riding.

To apply the parking brake lock

Pull the parking brake lever back to lock the rear wheel.


⌋ Be sure the release button pops out and parking brake lever is not released.

⌋ The parking brake lock will not function if the parking brake is not adjusted properly. (P89)

To release the parking brake lock

Release the parking brake lever by lightly pulling in the lever (a) and pressing the release button (b).

⌋ Before riding, check that the parking brake indicator is turned off and make sure that the parking brake is fully released so there is no drag on the rear wheel.



Hazard switch (P32)

Shift up switch (+)

To shift up the gear. (P51)

Headlight dimmer/ Passing light control switch

- ☰☐ : High beam
- ☰☐ : Low beam
- ☰☐ : Flashes the high beam headlight.




Turn signal switch

(P34)

Shift down switch (-)

To shift down the gear.
(P52)

**Horn button****N-D Switch**

To shift between Neutral and AT MODE. (P49)

**Start button**

Headlight turns off when operating the starter motor.

Torque Control switch

Torque Control level setting and Torque Control on/off.
(P40)

Ignition Switch

Switches the electrical system on/off, locks the steering.


- Key can be removed when in the OFF or LOCK position.


Steering Lock (P33)**A/M Switch**

To shift between the AT MODE and MT MODE.

(P49)

Engine stop switch

Should normally remain in the  (Run) position.


- In an emergency, switch to the  (Off) position (the starter motor will not operate) to stop the engine.

Handle Grip Heater

VFR1200XA/XDA

This motorcycle is equipped with a handle grip heater that warms up your hands during ride.

Wear gloves to protect your hands from the heated grips.



Handle grip heater indicator



Handle grip heater switch

Handle grip heater indicator:

Displayed when handle grip heater is on.

The selected heater level is indicated by the number of times the indicator blinks when the heater is turned on and the heater level is changed. For example, If you select heater level 5, the indicator blinks 5 times and repeats it 7 times.



Heater level:

The selected heater level is indicated for a few seconds in the clock area, when the handle grip heater switch is operated.

Handle grip heater status icon:

Displayed when the handle grip heater is on.

| If "E1", "E2" or "E3" blinks (P109)



To operate handle grip heater

- a Start the engine. (P42)
- b Press the handle grip heater switch. The handle grip heater is on.
 - ⊃ The status icon will be appeared on the display when the handle grip heater operates.
- c Select the heater level by pressing the switch.
 - ⊃ The clock on the display automatically switch to the indication of the heater level. The indication will return to the ordinary mode after blinking for about 5 seconds.
 - ⊃ Do not leave the handle grip heater in the high position for a long time on a warm day.


To turn off handle grip heater

To turn off, press the switch until handle grip heater status icon disappears. Also to turn off, press and hold the switch.

Do not use the handle grip heater with the engine at idle for a long time. It may result in a low (or dead) battery.

Maintains the selected level when the ignition switch is turned off.

No indication (Off)



- > Press the handle grip heater switch
- > Press and hold the handle grip heater switch

Maintains the selected level when the ignition switch is turned off.

- ⊃ The heater level is not changed if the ignition switch is turned to the OFF position within 5 seconds after heater level changed.

Honda selectable torque control (Torque Control)

Torque Control level (engine power control) can be selected or turned on/off.

- ⌋ Do not operate the Torque Control switch while riding. Stop the motorcycle first and the turn off or on and select the desired level.
- ⌋ The Torque Control setting cannot be changed or turned off when the system is activated (Torque Control indicator flashing).
- ⌋ Each time the ignition switch is turned to the ON position, the Torque Control level will automatically be set to level 3 (max).
- ⌋ When the Torque Control is turned from the off position to the on position, it will automatically be set to level 3 (max).


Torque Control level setting

The level can be selected by pressing the Torque Control switch.


- ⌋ Level 3 is the maximum Torque Control level
- ⌋ Level 1 is the minimum Torque Control level

Torque Control on and off

Torque Control can be turned on and off by press and hold the Torque Control switch.




Torque Control switch



Starting the Engine



VFR1200X/XA

Start your engine using the following procedure, regardless of whether the engine is cold or warm.



NOTICE

- If the engine does not start within 5 seconds, turn the ignition off and wait 10 seconds before trying to start the engine again to recovery of battery voltage.
- Extended fast idling and revving the engine can damage the engine, and the exhaust system.
- Snapping the throttle or fast idling for more than about 5 minutes may cause exhaust pipe discoloration.
- The engine will not start if the throttle is fully open.

- !a Make sure the engine stop switch is in the  (Run) position.
- !b Turn the ignition switch to the ON position.
- !c Shift the transmission to Neutral ( indicator comes on). Alternatively, pull in the clutch lever to start your motorcycle with the transmission in gear so long as the side stand is raised.
- !d Press the start button with the throttle completely closed.


If the engine does not start:

- a Open the throttle fully and press the start button for 5 seconds.
- b Repeat the normal starting procedure.
- c If the engine starts, open the throttle slightly if idling is unstable.
- d If the engine does not start, wait 10 seconds before trying steps a & b again.



! If Engine Will Not Start (P103)

VFR1200XD/XDA


Start your engine using the following procedure, regardless of whether the engine is cold or warm.

**NOTICE**

- If the engine does not start within 5 seconds, turn the ignition off and wait 10 seconds before trying to start the engine again to recovery of battery voltage.
- Extended fast idling and revving the engine can damage the engine, and the exhaust system.
- Snapping the throttle or fast idling for more than about 5 minutes may cause exhaust pipe discolouration.
- The engine will not start if the throttle is fully open.

- Make sure the engine stop switch is in the  (Run) position.
- Turn the ignition switch to the ON position.
- Check the transmission in Neutral ( indicator comes on).
- Press the start button with the throttle completely closed.
- Make sure the parking brake lever is released before riding.


If Engine Does Not Start (P103)**When you stop the engine**

- To stop the engine, put gear to Neutral ( indicator comes on).
 - If you turn the ignition switch to the OFF position when the motorcycle in gear, the engine will shut off with the clutch disengaged.
- Turn the ignition switch off.
- Pull the parking brake lever when you park the motorcycle.

Shifting Gears

VFR1200X/XA

Your motorcycle transmission has 6 forward gears in a one-down, five-up shift pattern.



If you put the motorcycle in gear with the side stand down, the engine will shut off.

Recommended Shift Points

Shifting Up

From 1st to 2nd	12 mph (20 km/h)
From 2nd to 3rd	19 mph (30 km/h)
From 3rd to 4th	25 mph (40 km/h)
From 4th to 5th	31 mph (50 km/h)
From 5th to 6th	37 mph (60 km/h)

Shifting Down

From 6th to 5th	28 mph (45 km/h)
From 5th to 4th	22 mph (35 km/h)
From 4th to 3rd	16 mph (25 km/h)

NOTICE

Improper shifting can damage the engine, transmission, and drive train. Also, coasting or towing the motorcycle for long distances with the engine off can damage the transmission.

VFR1200XD/XDA

Your motorcycle is equipped with an automatically controlled 6-speed transmission. It can be shifted automatically (by AT MODE) or manually (by MT MODE).

Recommended Shift Points**Shifting Up**

From 1st to 2nd	16 mph (25 km/h)
From 2nd to 3rd	22 mph (35 km/h)
From 3rd to 4th	28 mph (45 km/h)
From 4th to 5th	34 mph (55 km/h)
From 5th to 6th	37 mph (60 km/h)

Shifting Down

From 6th to 5th	34 mph (55 km/h)
From 5th to 4th	31 mph (50 km/h)
From 4th to 3rd	25 mph (40 km/h)
From 3rd to 2nd	19 mph (30 km/h)
From 2nd to 1st	12 mph (20 km/h)

NOTICE

Improper shifting can damage the engine, transmission, and drive train. Also, coasting or towing the motorcycle for long distances with the engine off can damage the transmission.

Shifting Gears *(Continued)*

VFR1200XD/XDA


Dual Clutch Transmission

In order to respond to rider demands in a broad range of situations, the transmission is equipped with three operating modes, AT MODE (including D mode for regular operation and three level of S mode for sporty riding); and MT MODE (MT mode for a 6-speed manual operation), which delivers the same shift feel as a manual transmission.

- Always use the recommended tires and sprockets to ensure correct the Dual Clutch Transmission operation.

The Dual Clutch Transmission system runs a self check immediately after starting the engine.

"-" appears in the gear position indicator window for a few seconds, then goes out. While "-" appears, you cannot shift into gear.



Neutral (N): Neutral is selected automatically when you turn the ignition switch to on.

If neutral is not selected when you turn the ignition switch to on:

- ⊣ Turn the ignition off and on again.
- ⊣ If neutral is still not selected after turning the engine off then on again. (P108)
You may hear (click) noises when the transmission shifts to Neutral (N). This is normal.

When you can change between N and D

- ⊣ Motorcycle is stopped and the engine is idling.
- ⊣ Throttle is completely closed. It is not possible to change from Neutral to D mode while the throttle is applied.
- ⊣ You cannot change between N and D mode while the wheels are rotating.
- ⊣ Side stand is raised.

NOTICE

To prevent clutch damage, do not use the throttle to keep the motorcycle stopped uphill.

Shifting Gears *(Continued)*

AT MODE: In this mode the gears are shifted automatically according to your riding conditions.

And also using the shift up switch (+), shift down switch (-), you can temporarily shift up or down in AT MODE by using the shift switch. These switches are convenient when you want to temporarily down-shift in front of a curve, etc. (P52)

You can choose between two modes within AT MODE: D mode and S mode.

D mode (AT): This is the standard mode when AT MODE is selected. Select D mode for regular operation and efficient fuel economy.

S mode (AT): Select this mode while riding in AT MODE when you need more power, such as when overtaking, climbing hills, pulling away.

S mode has three levels of adjustment.

MT MODE: MT MODE (6-speed manual operation) You can choose between 6 gears in this mode.

Changing between Neutral and AT MODE/MT MODE

Changing from Neutral (N) to AT MODE

Press the D/S side of the N-D switch (a).
The D mode indicator comes on, "1" is shown in the gear position indicator and first gear is selected.

Changing from AT or MT MODE to Neutral

Press N on the N-D switch (b).


Changing between D mode and S mode while in AT MODE

Press the D/S side of the N-D switch. The S or D mode indicator comes on (c , d).

Changing between AT MODE and MT MODE

Press the A/M switch (e).

The S or D indicator goes out while MT MODE is selected (f).




Shifting Gears *(Continued)*


S mode level selecting while in AT MODE

While in S mode, press and hold the D/S side of the N-D (a) switch.

- Close the throttle completely. Then select the desired level of the S mode.



- Press and hold the D/S side of the N-D button
- Press the D/S side of the N-D button



The selected level is maintained even when the ignition switch is turned off, or transmission is switched to out of S mode.

Riding in MT MODE

Shift up and down with the shift up switch (+) and shift down switch (-).

The selected gear is shown on the gear position indicator.

- ⌋ If the MT MODE is selected, the transmission does not shift up automatically. Do not allow the engine revs to go into the red zone.
- ⌋ The transmission automatically shifts down when you slow down, even in MT MODE.
- ⌋ You will start from 1st gear even if MT MODE is selected.

Downshifting Blipping Control

In MT mode, this system controls down shifting with the throttle completely closed by increasing engine revs automatically to match the gear ratio.

- ⌋ This system may not increase engine revs in some running conditions.

Shifting Gears *(Continued)*

Gear shift operation

Shifting Up:


Press the shift up switch (+) (g).

Shifting Down:

Press the shift down switch (-) (h).

You cannot continue shifting gear by keeping the shift switch pressed.


To continue shifting gear release the switch and press it again.



Shift Limit

You can't shift down if the engine revs exceed the limit.

Refueling



Do not fill with fuel above the level plate.

Fuel type: Unleaded gasoline only

Recommended fuel octane number:

Pump Octane Number (PON) 91 or higher.

Tank capacity: 5.68 US gal (21.5 liters)

Refueling and Fuel Guideline (P13)

Opening the Fuel Fill Cap

Open the lock cover, insert the ignition key,

and turn it clockwise to open the cap.

Closing the Fuel Fill Cap

- 1a After refueling, push the fuel fill cap closed until it locks.
- 1b Remove the key and close the cover.
 - ⌞ The key cannot be removed if the cap is not locked.


3 WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

Storage Equipment

A helmet holder, a helmet set wire (in the tool kit) and a tool kit are located under the seat. The document bag is located on the underside of the seat.



Helmet holder

Rear carrier


Never exceed the maximum weight limit.

Maximum Weight: 22 lb (10 kg)

□ Use the helmet holder only when parked.

■ **Removing the seat** (P78)

Underside of the seat



Document bag

3 WARNING

Riding with a helmet attached to the holder can interfere with your ability to safely operate the motorcycle and could lead to a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.


Accessory Socket

The accessory socket is located near the Torque Control switch.

Open the cover to access to the accessory socket.

Rated capacity is
36W (12V, 3A).

Accessory socket



Cover

- ⌋ To prevent the battery from becoming weak (or dead), keep the engine running while drawing current from the socket.
- ⌋ Set the headlight on low beam while the socket is in use. The battery may run down or cause damage to the accessory socket.
- ⌋ To prevent entry of foreign matter into the socket, be sure to close the cover when the accessory socket is not used.

Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

An optional larger tool kit may be available. Check with your Honda dealer’s parts department.

Importance of Maintenance	P. 57	Side Stand	P. 91
Maintenance Schedule	P. 59	Clutch	P. 92
Maintenance Fundamentals	P. 62	Throttle	P. 93
Removing & Installing Body Components ...	P. 74	Other Adjustments	P. 95
Battery	P. 74	Headlight Aim	P. 95
Clip	P. 75	Clutch and Brake Levers	P. 96
Right Engine Heat Guard & Right Under		Front Suspension	P. 97
Fairing	P. 76	Rear Suspension	P. 98
Seat	P. 78	Windscreen Height	P. 100
Engine Oil	P. 79		
Coolant	P. 85		
Brakes	P. 87		

Importance of Maintenance

Keeping your motorcycle well-maintained is absolutely essential to your safety and to protect your investment, obtain maximum performance, avoid breakdowns, and reduce air pollution. Maintenance is the owner's responsibility. Be sure to inspect your motorcycle before each ride, and perform the periodic checks specified in the Maintenance Schedule. 2 P. 59

3 WARNING

Improperly maintaining your motorcycle or failing to correct a problem before you ride can cause a crash in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual.

For information about the exhaust emission and noise emission requirements of the U.S. Environmental Protection Agency (EPA), the California Air Resources Board (CARB), and the Environment Canada (EC). 2 P. 134

USA

Maintenance, replacement or repair of the emission control devices and systems may be performed by any motorcycle repair establishment or individual using parts that are "certified" to EPA standards.

Maintenance Safety

Always read the maintenance instructions before you begin each task, and make sure that you have the tools, parts, and skills required. We cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

Follow these guidelines when performing maintenance.

- Stop the engine and remove the key.
- Place your motorcycle on a firm, level surface using the side stand, center stand (VFR1200XA/XDA) or a maintenance stand to provide support.
- Allow the engine, muffler, brakes, and other high-temperature parts to cool before servicing as you can get burned.
- Run the engine only when instructed, and do so in a well-ventilated area.










Maintenance Schedule

The maintenance schedule specifies the maintenance requirements necessary to ensure safe, dependable performance, and proper emission control.


Maintenance work should be performed in accordance with Honda's standards and specifications by properly trained and equipped technicians. Your dealer meets all of these requirements. Keep an accurate record of maintenance to help ensure that your motorcycle is properly maintained. Make sure that whomever performs the maintenance completes this record.


All scheduled maintenance is considered a normal owner operating cost and will be charged for by your dealer. Retain all receipts. If you sell the motorcycle, these receipts should be transferred with the motorcycle to the new owner.

Maintenance Schedule

Items		Frequency*1								Regular Replace	Refer to page
		x 1,000 mi	0.6	4	8	12	16	20	24		
		x 1,000 km	1.0	6.4	12.8	19.2	25.6	32.0	38.4		
Emission-related Items	Fuel Line 				I		I		I		-
	Throttle Operation 				I		I		I		93
	Air Cleaner*2 					R			R		70
	Spark Plug 	Every 16,000 mi (25,600 km): I Every 32,000 mi (51,200 km): R									-
	Valve Clearance 						I				-
	Engine Oil		R		R		R		R	1 Year	79
	Engine Oil Filter		R				R				80
	Clutch Oil Filter*6		R				R				83
	Engine Idle Speed 				I		I		I		-
	Radiator Coolant*4				I		I		I	3 Years	85
	Cooling System 				I		I		I		-
	Secondary Air Supply System 						I				-
Evaporative Emission Control System*3 						I				-	

Maintenance Level

 : Intermediate. We recommend service by your dealer, unless you have the necessary tools and are mechanically skilled. Procedures are provided in an official Honda Service Manual (2 P. 141).

 : Technical. In the interest of safety, have your motorcycle serviced by your dealer.






























































Maintenance Legend

I : Inspect (clean, adjust, lubricate, or replace, if necessary)

R : Replace

L : Lubricate

C : Clean

Items		Frequency*1									Regular Replace	Refer to page
		x 1,000 mi	0.6	4	8	12	16	20	24			
		x 1,000 km	1.0	6.4	12.8	19.2	25.6	32.0	38.4			
Non-Emission-Related Items	Final Drive Oil										3 Years	69
	Brake Fluid*4										2 Years	87
	Brake Pads Wear											88
	Brake System											62
	Brake Light Switch											90
	Brake Lock Operation*6											89
	Headlight Aim											95
	Clutch System*5											96
	Clutch Fluid*4, *5										2 Years	92
	Side Stand											91
	Suspension											-
	Nuts, Bolts, Fasteners											-
	Wheels/Tires											70
Steering Head Bearings											-	

Notes:

- *1 : At higher odometer readings, repeat at the frequency interval established here.
- *2 : Service more frequently when riding in unusually wet or dusty areas.
- *3 : 50 STATE (meets California).
- *4 : Replacement requires mechanical skill.
- *5 : VFR1200X/XA
- *6 : VFR1200XD/XDA

Pre-ride Inspection

To ensure safety, it is your responsibility to perform a pre-ride inspection and make sure that any problem you find is corrected. A pre-ride inspection is a must, not only for safety, but because having a breakdown, or even a flat tire, can be a major inconvenience.

Check the following items before you get on your motorcycle:

- Tire tread wear and air pressures are within limits. [↗ P. 70](#)
- Lights, horn, and turn signals operate normally.
- Suspension is adjusted to suit load. [↗ P. 97, 98](#)

Check the following items if you are carrying a passenger or cargo:

- Combined weight is within load limits. [↗ P. 147](#)
- Cargo is secured properly.

Check the following items after you get on your

motorcycle:

- Throttle action moves smoothly without binding. [↗ P. 93](#)
- Brake lever and pedal operate normally.
- Check the fuel level and refuel when needed. [↗ P. 13, 53](#)
- Engine stop switch functions properly. [↗ P. 32, 37](#)

Check the following items at regular intervals:

- Oil level is between the upper and lower level marks. [↗ P. 79](#)
- Brake fluid level is
Front: above the LOWER level mark. [↗ P. 87](#)
Rear: between the UPPER and LOWER level marks. [↗ P. 87](#)
- **VFR1200X/XA** Clutch fluid level is above the LOWER level mark. [↗ P. 92](#)
- Engine coolant level is between the UPPER and LOWER level marks. [↗ P. 85](#)
- Side stand functions properly. [↗ P. 91](#)
- **VFR1200XD/XDA** Parking brake works properly. [↗ P. 89](#)

Periodic Checks

You should also perform other periodic maintenance checks at least once a month regardless of how often you ride, or more often if you ride frequently.


Also, check the odometer reading against the Maintenance Schedule and perform all maintenance that is due. ≥ P. 59

Tires and wheels	Check the air pressure (≥ P. 70), examine tread for wear and damage (≥ P. 70), and check the wheels for damage.
Fluid levels	Check the engine oil level (≥ P. 79), engine coolant level (≥ P. 85), and brake fluid level (≥ P. 87).
Lights	Check that the headlight, position lights, brake/taillight, turn signals, license plate light are working properly.
Controls	Check the freeplay of the throttle grip (≥ P. 93), the clutch lever (VFR1200X/XA) (≥ P. 96), Check the front brake lever (≥ P. 96), rear brake pedal, and parking brake (VFR1200XD/XDA) (≥ P. 89) operate properly.
Fuses	Check that you have a full supply of spare fuses.
Nuts & bolts	Check the major nuts and bolts, and tighten as needed.

Replacing Parts

Always use Honda Genuine Parts or their equivalents to ensure reliability and safety.

When ordering colored components, specify the model name, color, and code mentioned on the color label. The color label is attached to the rear fender under the seat. 2 P. 78



3 WARNING

Installing non-Honda parts may make your motorcycle unsafe and cause a crash in which you can be seriously hurt or killed.

Always use Honda Genuine Parts or equivalents that have been designed and approved for your motorcycle.

Battery

Your motorcycle has a maintenance-free type battery. You do not have to check the battery electrolyte level or add distilled water. Clean the battery terminals if they become dirty or corroded.

Do not remove the battery cap seals. There is no need to remove the cap when charging.

What to do in an emergency

If any of the following occur, immediately see your doctor.

- Electrolyte splashes into your eyes:
 - ⊣ Wash your eyes repeatedly with cool water for at least 15 minutes. Using water under pressure can damage your eyes.
- Electrolyte splashes onto your skin:
 - ⊣ Remove affected clothing and wash your skin thoroughly using water.

- Electrolyte splashes into your mouth:
 - ⊣ Rinse mouth thoroughly with water, and do not swallow.

3 WARNING

The battery gives off explosive hydrogen gas during normal operation.

A spark or flame can cause the battery to explode with enough force to kill or seriously hurt you.


Wear protective clothing and a face shield, or have a skilled mechanic do the battery servicing.

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds.

Wash your hands after handling.

Cleaning the Battery Terminals

1. Remove the battery. 2 P. 74
2. If the terminals are starting to corrode and are coated with a white substance, wash with warm water and wipe clean.
3. If the terminals are heavily corroded, clean the terminals with a wire brush or sandpaper. Wear safety glasses.



4. After cleaning, reinstall the battery.

The battery has a limited life span. Consult your dealer about when you should replace the battery. Always replace the battery with another maintenance-free battery of the same type.

Charging

If you use electrical accessories that drain the battery or you do not ride frequently, we recommend that you charge the battery every 30 days using a charger designed specifically for your Honda, which can be purchased from your dealer. Read the information that came with your battery charger and follow the instructions on the battery. Avoid using an automobile-type battery charger, as these can overheat a motorcycle battery and cause permanent damage.

Make sure the ignition switch is in the OFF position before charging the battery.

NOTICE

Improper charging can damage the battery. If you can't charge the battery or it appears unable to hold a charge, contact your dealer.

NOTICE

Jump starting using an automobile battery can damage your motorcycle's electrical system and is not recommended. Bump starting is also not recommended.

NOTICE


Installing non-Honda electrical accessories can overload the electrical system, discharging the battery and possibly damaging the system.

Fuses

Fuses protect the electrical circuits on your motorcycle. If something electrical on your motorcycle stops working, check for and replace any blown fuses. 2 P. 121

Inspecting and Replacing Fuses

Turn off the ignition switch to remove and inspect fuses. If a fuse is blown, replace with a fuse of the same rating. For fuse ratings, see "Specifications." 2 P. 149

**NOTICE**

Replacing a fuse with one that has a higher rating greatly increases the chance of damage to the electrical system.

If a fuse fails repeatedly, you likely have an electrical fault. Have your motorcycle inspected by your dealer.

Engine Oil

Engine oil consumption varies and oil quality deteriorates according to riding conditions and time elapsed.

Check the engine oil level regularly, and add the recommended engine oil if necessary. Dirty oil or old oil should be changed as soon as possible.


Selecting the Engine Oil

For recommended engine oil, see "Specifications." 2 P. 148


If you use non-Honda engine oil, check the label to make sure that the oil satisfies all of the following standards:

- JASO T 903 standard*1: MA
- SAE standard*2: 10W-30
- API classification*3: SG or higher

*1. The JASO T 903 standard is an index for engine oils for 4-stroke motorcycle engines. There are two classes: MA and MB. For example, the following label shows the MA classification.



- *2. The SAE standard grades oils by their viscosity.
- *3. The API classification specifies the quality and performance rating of engine oils. Use SG or higher oils, excluding oils marked as "Energy Conserving" or "Resource Conserving" on the circular API service symbol.



Brake Fluid (Clutch Fluid)

Do not add or replace brake fluid, except in an emergency. Use only fresh brake fluid from a sealed container. If you do add fluid, have the brake and clutch system serviced by your dealer as soon as possible.

NOTICE

Brake fluid can damage plastic and painted surfaces. Wipe up spills immediately and wash thoroughly.

Recommended brake fluid:

Honda DOT 4 Brake Fluid or equivalent

3 WARNING

Clean filler cap before removing. Use only DOT 4 fluid from a sealed container.

Final Drive Oil

Recommended final drive oil:

Hypoid gear oil SAE 80

Recommended Coolant

Pro Honda HP coolant is a pre-mixed solution of antifreeze and distilled water.

Concentration:

50% antifreeze and 50% distilled water

A concentration of antifreeze below 40% will not provide proper corrosion and cold temperature protection.

A concentration of up to 60% will provide better protection in colder climates.

NOTICE

Using coolant not specified for aluminum engines or using ordinary tap water can cause corrosion.

Air Cleaner

This motorcycle is equipped with a viscous type air cleaner element which cannot be cleaned with compressed air or otherwise without degrading its performance.

If the filter becomes dirty, replace it with a new one.


Tires (Inspecting/Replacing)

Checking the Air Pressure

Visually inspect your tires and use an air pressure gauge to measure the air pressure at least once a month or any time you think the tires look low. Always check air pressure when your tires are cold. 2 P. 148


Inspecting for Damage

Inspect the tires for cuts, slits, or cracks that exposes fabric or cords, or nails or other foreign objects embedded in the side of the tire or the tread. Also inspect for any unusual bumps or bulges in the side walls of the tires.




Inspecting for Abnormal Wear

Inspect the tires for signs of abnormal wear on the contact surface.



Inspecting Tread Depth

Inspect the tread wear indicators. If they become visible, replace the tires immediately. For safe riding, you should replace the tires when the minimum tread depth is reached.



3 WARNING

Riding on tires that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding tire inflation and maintenance.

Maintenance Fundamentals

Have your tires replaced by your dealer. For recommended tires, air pressure and minimum tread depth, see “Specifications.” 2 P. 148

Follow these guidelines whenever you replace tires.

- Use the recommended tires or equivalents of the same size, construction, speed rating, and load range.
- Have the wheel balanced with Honda Genuine balance weights or equivalent after the tire is installed.
- Do not install a tube inside a tubeless tire on this motorcycle. Excessive heat build-up can cause the tube to burst.
- Use only tubeless tires on this motorcycle. The rims are designed for tubeless tires, and during hard acceleration or braking, a tube-type tire could slip on the rim and cause the tire to rapidly deflate.

3 WARNING

Installing improper tires on your motorcycle can adversely affect handling and stability, and can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tires recommended in this owner's manual.

Tire Service Life

The service life of your tires is dependent on many factors, including, but not limited to, riding habits, road conditions, vehicle loading, tire air pressure, maintenance history, speed, and environmental conditions (even when the tires are not in use).

In addition to your regular inspections and maintenance, it is recommended that you have annual inspections performed once the tires reach 5 years old. It is also recommended that all tires be removed from service after 10 years from the date of manufacture, regardless of their condition or state of wear.

The last four digits of the TIN (tire identification number) indicate the date of manufacture.

Tire Identification Number (TIN)


The tire identification number (TIN) is a group of numbers and letters located on the sidewall of the tire.

a b c


DOT XXXX XXXX 22 09

DOT: This indicates that the tire meets all requirements of the U.S. Department of Transportation.

- a XXXX: Factory code
- b XXXX: Tire type code
- c 22 09: Date of manufacture (week & year).
Example: week 22 in year 09.



Battery



Removal

Make sure the ignition switch is off.

1. Remove the seat. 2 P. 78
2. Unhook the rubber strap.
3. Disconnect the negative - terminal from the battery.
4. Disconnect the positive + terminal from the battery.
5. Remove the battery taking care not to drop the terminal nuts.

Installation

Install the parts in the reverse order of removal. Always connect the positive + terminal first. Make sure that bolts and nuts are tight.


Make sure the clock is set to the proper time after the battery is reconnected. 2 P. 24

For proper handling of the battery, see "Maintenance Fundamentals." 2 P. 62
"Battery Goes Dead" 2 P. 117

Clip


Removal

1. Press down on the center pin to release the lock.
2. Pull the clip out of the hole.



Installation


1. Push the bottom of the center pin.
2. Insert the clip into the hole.
3. Press down on the center pin to lock the clip.



Right Engine Heat Guard & Right Under Fairing


Removal

1. Remove the clip. 2 P. 75
2. Remove the prongs from the grommets.
3. Remove the right engine heat guard.




4. Remove the bolts.
5. Remove the prong from the grommet.
6. Remove the right under fairing.

VFR1200X/XA




VFR1200XD/XDA



Installation

Install the parts in the reverse order of removal.

Seat



Removal

1. Insert the ignition key into the seat lock, and turn and hold the key clockwise to unlock the seat.
2. Pull the rear of the seat back and up.

Installation


1. Insert the front and rear prongs into the front and rear stays on the frame.
2. Push forward and down on the rear of the seat until it locks in place.

Make sure that the seat is locked securely in position to pull it up lightly.

The seat locks automatically when closed. Take care not to lock your key in the underseat compartment.

Checking the Engine Oil

1. If the engine is cold, idle the engine for 3 to 5 minutes.
2. Turn the ignition switch off and wait for 2 to 3 minutes.
3. Place your motorcycle in an upright position on a firm, level surface.
4. Check that the oil level is between the upper level and lower level marks in the oil level inspection window.



Adding Engine Oil

If the engine oil is below or near the lower level mark, add the recommended engine oil.
≥ P. 68

1. Remove the oil fill cap. Add the recommended oil until it reaches the upper level mark.
 - ⊔ Place your motorcycle in an upright position on a firm, level surface when checking the oil level.
 - ⊔ Do not overfill above the upper level mark.
 - ⊔ Make sure no foreign objects enter the oil filler opening.
 - ⊔ Wipe up any spills immediately.
2. Securely reinstall the oil fill cap.

NOTICE

Overfilling with oil or operating with insufficient oil can cause damage to your engine. Do not mix different brands and grades of oil. They may affect lubrication and clutch operation.

For the recommended oil and oil selection guidelines, see "Maintenance Fundamentals." ≥ P. 62

Changing Engine Oil & Filter


Changing the oil and filter requires special tools. We recommend that you have your motorcycle serviced by your dealer.

Use a new Honda Genuine oil filter or equivalent specified for your model.

NOTICE


Using the wrong oil filter can result in serious damage to the engine.

1. Remove the right engine heat guard and right under fairing. ≥ P. 76
2. If the engine is cold, idle the engine for 3 to 5 minutes.
3. Turn the ignition switch off and wait for 2 to 3 minutes.
4. Place on a firm, level surface and lower the side stand.
5. Place a drain pan under the drain bolt.
6. Remove the oil fill cap, drain bolt, and sealing washer to drain the oil.



- Remove the oil filter with a filter wrench and let the remaining oil drain out. Make sure the prior seal is not stuck to the engine.

\cup Discard the oil and oil filter at an approved recycling center.



- Apply a thin coat of engine oil to the rubber seal of a new oil filter.
- Install the new oil filter and tighten.

Torque: 19 lbf·ft (26 N·m, 2.7 kgf·m).

- Install a new sealing washer onto the drain bolt. Tighten the drain bolt.

Torque: 21 lbf·ft (29 N·m, 3.0 kgf·m).

11. Fill the crankcase with the recommended oil (2 P. 68) and install the oil fill cap.

Required oil

VFR1200X/XA

When changing oil & engine oil filter:

3.5 US qt (3.3 litres)

When changing oil only:

3.3 US qt (3.1 litres)

VFR1200XD/XDA

When changing oil & engine oil filter:

4.1 US qt (3.9 litres)

When changing oil only:

3.8 US qt (3.6 litres)

12. Check the oil level. 2 P. 79
13. Check that there are no oil leaks.
14. Install the right engine heat guard and right under fairing.

Changing Clutch Oil Filter

VFR1200XD/XDA


Use a new Honda Genuine clutch oil filter or equivalent specified for your model.

NOTICE

Using the wrong clutch oil filter can result in serious damage to the transmission.

1. Follow the steps 1-7 of Changing Engine Oil & Filter. ↳ P. 80

2. Remove the clutch oil filter cover, clutch oil filter and spring by removing the clutch oil filter bolts A and B.
 - ↳ Discard the oil and clutch oil filter at an approved recycling center.



Engine Oil Changing Clutch Oil Filter

3. Install the new clutch oil filter with the rubber seal facing in, toward the engine. You will see "IN-SIDE" mark on the clutch oil filter body, near the seal.
4. Replace the O-ring and apply a thin coat of engine oil to the new O-ring when before installing it.
5. Install the spring and the clutch oil filter cover.
6. Install the clutch oil filter bolts A, B and tighten.
7. Apply a thin coat of engine oil to the rubber seal of a new engine oil filter.
≥ P. 81
8. Install a new engine oil filter and tighten.

Torque: 19 lbf·ft (26 N·m, 2.7 kgf·m).

9. Install a new sealing washer onto the drain bolt. Tighten the drain bolt.

Torque: 21 lbf·ft (29 N·m, 3.0 kgf·m).

10. Fill the crankcase with the recommended oil (≥ P. 68) and install the oil fill cap.

Required oil

When changing oil, engine oil filter & clutch oil filter:


4.2 US qt (4.0 litres)

11. Check the oil level. ≥ P. 79
12. Check that there are no oil leaks.
13. Install the right engine heat guard and right under fairing.

Checking the Coolant

Check the coolant level in the reserve tank while the engine is cold.

1. Place your motorcycle on a firm, level surface.
2. Hold your motorcycle in an upright position.
3. Check that the coolant level is between the UPPER level and LOWER level marks in the reserve tank.





If the coolant level is dropping noticeably or the reserve tank is empty, you likely have a serious leak. Have your motorcycle inspected by your dealer.

Adding Coolant

If the coolant level is below the LOWER level mark, add the recommended coolant \geq P. 69 until the level reaches the UPPER level mark. Add fluid only from the reserve tank cap and do not remove radiator cap.

1. Remove the right engine heat guard.
 \geq P. 76

Coolant Changing Coolant

2. Remove the reserve tank cap and add fluid while monitoring the coolant level.
 -  Do not overfill above the UPPER level mark.
 -  Make sure no foreign objects enter the reserve tank opening.
3. Securely reinstall the cap.
4. Reinstall the right engine heat guard.

3 WARNING

Removing the radiator cap while the engine is hot can cause the coolant to spray out, potentially scalding you.

Always let the engine and radiator cool down before removing the radiator cap.

Changing Coolant

Have your dealer change the coolant unless you have the proper tools and are mechanically qualified.

Checking Brake Fluid


1. Place your motorcycle in an upright position on a firm, level surface.
2. **Front** Check that the brake fluid reservoir is horizontal and that the fluid level is above the LOWER level mark.
3. **Rear** Check that the brake fluid reservoir is horizontal and that the fluid level is between the LOWER level and UPPER level marks.

If the brake fluid level in either reservoir is below the LOWER level mark or the brake lever and pedal freeplay becomes excessive, inspect the brake pads for wear. If the brake pads are not worn, you most likely have a leak. Have your motorcycle inspected by your dealer.

Front

Front brake
fluid reservoir

LOWER level
mark




Rear

Rear brake
fluid reservoir


UPPER level
mark

LOWER level
mark



Inspecting the Brake Pads

Check the condition of the brake pad wear indicators. The pads need to be replaced if a brake pad is worn to the wear indicator.




1. **Front** Inspect the brake pads from below the brake caliper.
 - U Always inspect both left and right calipers.
2. **Rear** Inspect the brake pads from the rear left of the motorcycle.

If necessary have the pads replaced by your dealer.

Always replace both left and right brake pads at the same time.

Inspecting the Parking Brake

VFR1200XD/XDA




Place your motorcycle on a firm, level surface. Stop the engine and push your motorcycle while applying the parking brake lever to check the efficacy of the parking brake.


If the efficacy of the parking brake become weak, have the brake adjusted by your dealer.

Adjusting the Brake Light Switch

Check the operation of the brake light switch. Hold the brake light switch and turn the adjusting nut in the direction A if the switch operates too late, or turn the nut in the direction B if the switch operates too soon.



Checking the Side Stand



1. Check that the side stand operates smoothly. If the side stand is stiff or squeaky, clean the pivot area and lubricate the pivot bolt with clean grease.
2. Check the spring for damage or loss of tension.

3. VFR1200X/XA

Sit on the motorcycle, put the transmission in Neutral, and raise the side stand.

VFR1200XD/XDA

Sit on the motorcycle and raise the side stand.

4. VFR1200X/XA

Start the engine, pull the clutch lever in, and shift the transmission into gear.


VFR1200XD/XDA

Start the engine and press the D/S side of N-D switch to switch the transmission into D mode.

5. Lower the side stand all the way. The engine should stop as you lower the side stand. If the engine doesn't stop, have your motorcycle inspected by your dealer.

Checking Clutch Fluid

VFR1200X/XA



1. Place your motorcycle in an upright position on a firm, level surface.
2. Check that the clutch fluid reservoir is horizontal and that the fluid level is above the lower level mark.


If the fluid level is low or if you find fluid leaks, or deterioration or cracks in the hoses and fittings, have the clutch system serviced by your dealer.

Checking the Throttle

With the engine off, check that the throttle rotates smoothly from fully closed to fully open in all steering positions and throttle freeplay is correct. If the throttle does not move smoothly, close automatically, or if the cable is damaged, have the motorcycle inspected by your dealer.

Freeplay at the throttle grip flange:


1/16 to 3/16 in (2 to 4 mm)




Adjusting the Throttle Freeplay

1. Slide the cable boot.
2. Loosen the lock nut.
3. Turn the adjuster until the freeplay is 1/16 to 3/16 in (2 to 4 mm).
4. Tighten the lock nut, return the cable boot, and inspect the throttle action again.

VFR1200X/XA




VFR1200XD/XDA



Adjusting the Headlight Aim

You can adjust vertical aim of the headlight for proper alignment. Turn the knob in or out as necessary.

Obey local laws and regulations.



Adjusting the Clutch and Brake Levers

You can adjust the distances between the tip of the clutch lever and handle grip, and between the tip of the brake lever and handle grip.

Adjustment method


Turn the adjuster until the numbers align with the index mark while pushing the lever forward in the desired position.

After adjustment, check that the levers operate correctly before riding.

NOTICE

Do not turn the adjuster beyond its natural limit.


VFR1200XD/XDA is not equipped with clutch lever and clutch lever adjuster.



Adjusting the Front Suspension


I Spring Preload

You can adjust the spring preload by the adjuster to suit the load or the road surface. Turn clockwise to increase spring preload (hard), or turn counterclockwise to decrease spring preload (soft). Standard position: 5th groove (**VFR1200X/XA**)/4th groove (**VFR1200XD/XDA**). Align the desired position with the fork bolts surface.



I Rebound Damping

You can adjust the rebound damping by the adjuster to suit the load or the road surface. Turn clockwise to increase rebound damping (hard), or turn counterclockwise to decrease rebound damping (soft). The standard position is 7 clicks (**VFR1200X/XA**)/6 clicks (**VFR1200XD/XDA**) from the maximum setting.




NOTICE

Do not turn the adjuster beyond its natural limits.
Adjust both left and right forks to the same spring preload and rebound damping.

Adjusting the Rear Suspension


Spring Preload

You can adjust the spring preload by the adjuster knob to suit the load or the road surface. Turn clockwise to increase spring preload (hard), or turn counterclockwise to decrease spring preload (soft). The standard position is 7 clicks (**VFR1200X/XA**)/9 clicks (**VFR1200XD/XDA**) from the minimum setting.



I Rebound Damping

You can adjust the rebound damping by the adjuster to suit the load or the road surface. Turn clockwise to increase rebound damping (hard), or turn counterclockwise to decrease rebound damping (soft). The standard position is 1 $\frac{3}{8}$ turns (**VFR1200X/XA**)/ $\frac{7}{8}$ turns (**VFR1200XD/XDA**) from the maximum setting.



NOTICE

Do not turn the adjuster beyond its natural limits.

NOTICE

The rear shock absorber damper unit contains high pressure nitrogen gas. Do not attempt to disassemble, service, or improperly dispose of the damper. See your dealer.

Adjusting the Windscreen Height


You can adjust the windscreen height 1 of 5 positions.

Windscreen height indicator shows the windscreen height.


The standard position is 5.

U Do not adjust the windscreen while riding.

1. Pull the windscreen adjustment lever to unlock the windscreen.
2. Continue to pull the adjustment lever up, move the adjustment lever forward or backward to raise or lower the windscreen.



3. Release the windscreen adjustment lever at the desired position while checking height the indicator.
 - U Make sure that the windscreen is locked securely by slightly moving the windscreen adjusting grip up or down.



If the windscreen does not move smoothly, clean the sliders using a sponge or a soft towel with neutral detergent to remove dust.

- U Do not apply a lubricant to the sliders.

If the windscreen does not move smoothly after cleaning the sliders, have your motorcycle inspected by your dealer.

Troubleshooting

Engine Will Not Start	P. 103
Overheating (High coolant temperature indicator is on)	P. 104
Warning Indicators On or Flashing	P. 105
Low Oil Pressure Indicator	P. 105
PGM-FI (Programmed Fuel Injection)	
Malfunction Indicator Lamp (MIL)	P. 105
ABS (Anti-lock Brake System) Indicator	P. 106

If the “-” Indicator is Blinking in the Gear Position Window While Riding	P. 108
Other Warning Indications	P. 109
Fuel Gauge Failure Indication	P. 109
Tire Puncture	P. 110
Electrical Trouble	P. 117
Battery Goes Dead	P. 117
Burned-out Light Bulb	P. 117
Blown Fuse	P. 121


Starter Motor Operates But Engine Does Not Start

Check the following items:

- Check the correct engine starting sequence ≥ P. 42, 43
- Check that there is gasoline in the fuel tank
- Check if the PGM-FI malfunction indicator lamp (MIL) is on
 - If the indicator light is on, contact your dealer as soon as possible.

Starter Motor Does Not Operate

Check the following items:

- Make sure the engine stop switch is in the  (Run) position ≥ P. 32, 37
- Make sure the side stand is raised.
- Check for a blown fuse ≥ P. 121
- Check for a loose battery connection or battery terminal corrosion ≥ P. 66, 74
- Check the condition of the battery ≥ P. 117

If the problem continues, have your motorcycle inspected by your dealer.

Overheating (High coolant temperature indicator is on)

The engine is overheating when the following occurs:

- High coolant temperature indicator comes on.
- Acceleration becomes sluggish.

If this occurs, pull safely to the side of the road and perform the following procedure. Extended fast idling may cause the high coolant temperature indicator to come on.

NOTICE

Continuing to ride with an overheated engine can cause serious damage to the engine.

1. Stop the engine using the ignition switch, and then turn the ignition switch to the ON position.

2. Check that the radiator fan is operating, and then turn the ignition switch to the OFF position.

If the fan is not operating:

Suspect a fault. Do not start the engine. Transport your motorcycle to your dealer.

If the fan is operating:

Allow the engine to cool with the ignition switch in the OFF position.

3. After the engine has cooled, inspect the radiator hose and check if there is a leak.
≥ P. 85

If there is a leak:

Do not start the engine. Transport your motorcycle to your dealer.

4. Check the coolant level in the reserve tank, and add coolant as necessary.
≥ P. 85
5. If 1-4 check normal, you may continue riding, but closely monitor the high coolant temperature indicator.

Low Oil Pressure Indicator

If the low oil pressure indicator comes on, pull safely to the side of the road and stop the engine.

NOTICE

Continuing to ride with low oil pressure can cause serious damage to the engine.

1. Check the engine oil level, and add oil as necessary. \geq P. 79
2. Start the engine.
 - ⌋ Only continue riding if the low oil pressure indicator goes off.

Rapid acceleration may momentarily cause the low oil pressure indicator to come on, especially if the oil is at or near the low level. If the low oil pressure indicator stays on when the oil level is at the proper level, stop the engine and contact your dealer.

If the engine oil level goes down rapidly, your motorcycle may have a leak or another serious problem. Have your motorcycle inspected by your dealer.

PGM-FI (Programmed Fuel Injection) Malfunction Indicator Lamp (MIL)

If the indicator comes on while riding, you may have a serious problem with the PGM-FI system. Reduce speed and have your motorcycle inspected by your dealer as soon as possible.

ABS (Anti-lock Brake System) Indicator

If the indicator operates in one of the following ways, you may have a serious problem with the brake system. Reduce your speed and have your motorcycle inspected by your dealer as soon as possible.

- Indicator comes on or starts flashing while riding.
- Indicator does not come on when the ignition switch is in the ON position.
- Indicator does not go off at speeds above 6 mph (10 km/h).

If the ABS indicator stays on, your brakes will continue to work as a conventional system, but without the anti-locking function.

The ABS indicator may flash if you turn the rear wheel while your motorcycle is lifted off the ground. In this case, turn the ignition switch off and then on again. The ABS indicator will go off after your speed reaches 6 mph (10 km/h).

Torque Control Indicator

If the indicator operates in one of the following ways, you may have a serious problem with the Torque Control. Reduce your speed and have your motorcycle inspected by your dealer as soon as possible.

- Indicator comes and stays on (solid) while riding.
- Indicator does not come on when the ignition switch is turned on.
- Indicator does not go off at speeds above 6 mph (10 km/h).

Even when the Torque Control indicator is on, your motorcycle will have normal riding ability without Torque Control function.

- U When the indicator comes on while the Torque Control is in operation, you will have to completely close the throttle to regain normal riding ability.

The Torque Control indicator may come on if you rotate the rear wheel while your motorcycle is lifted off the ground. In this case, turn the ignition switch off and on again. The Torque Control indicator will go off after your speed reaches 6 mph (10 km/h).

If the “-” Indicator is Blinking in the Gear Position Window While Riding

VFR1200XD/XDA

If the “-” indicator is blinking while riding, you may have a serious problem with the Dual Clutch Transmission system.

Park your motorcycle in a safe place and have your motorcycle inspected by dealer immediately.

There is possibility for you to ride yourself to go to dealer if you try to follow the procedure below.

1. Turn the ignition switch to OFF.
2. Turn the ignition switch to ON and start the engine.

If you cannot start the engine:

Turn the ignition switch to OFF and move the motorcycle back and forth slightly (to disengage the gears).

Turn the ignition switch to ON again and start the engine.

If you still cannot start the engine:

Start the engine while applying the brake lever or pressing the brake pedal.

If you can shift from N to D mode:

When a gear position is shown in the gear position indicator, you can ride in that gear. Take your motorcycle to your dealer riding at a safe speed.


If you can't shift from N to D mode and the “-” indicator is blinking:

Damage is preventing you from riding. Have your motorcycle inspected by your dealer immediately.

Fuel Gauge Failure Indication

If the fuel system has an error, all segments will blink as shown in the illustration.

If this occurs, see your dealer as soon as possible.



Handle Grip Heater Failure Indication

VFR1200XA/XDA

If the handle grip heater system has an error, the handle grip heater status icon will blink. If the "E1", "E2" or "E3" blinking does not go off, see your dealer as soon as possible.

Handle grip heater status icon



Tire Puncture

Repairing a puncture or removing a wheel requires special tools and technical expertise. We recommend you have this type of service performed by your dealer.

After an emergency repair, always have the tire inspected/replaced by your dealer.

Emergency Repair Using a Tire Repair Kit

If your tire has a minor puncture, you can make an emergency repair using a tubeless tire repair kit.

Follow the instructions provided with the emergency tire repair kit.

Riding your motorcycle with a temporary tire repair is very risky. Do not exceed 30 mph (50 km/h). Have the tire replaced by your dealer as soon as possible.

3 WARNING

Riding your motorcycle with a temporary tire repair can be risky. If the temporary repair fails, you can crash and be seriously injured or killed.

If you must ride with a temporary tire repair, ride slowly and carefully and do not exceed 30 mph (50 km/h) until the tire is replaced.

Removing Wheels

Follow these procedures if you need to remove a wheel in order to repair a puncture.

When removing and installing the wheel, be careful not to damage the wheel speed sensor and pulser ring.

Front Wheel

Removal


1. Place on a firm, level surface.

VFR1200XA/XDA

Place your motorcycle on its center stand on a firm level surface.


2. Cover both sides of the front wheel and brake caliper with protective tape or cloth.
3. On the left side, remove the mounting bolts and remove the brake caliper.

4. On the right side, remove the mounting bolts and remove the brake caliper.
 - U Support the brake caliper assembly so that it doesn't hang from the brake hose. Do not twist the brake hose.
 - U Avoid getting grease, oil, or dirt on the disc or pad surfaces.
 - U Do not pull the brake lever or push the brake pedal while the brake caliper is removed.
 - U Take care to prevent the brake caliper from scratching the wheel during removal.




Tire Puncture □ Removing Wheels

5. Remove the front axle bolt.
6. Loosen the right axle pinch bolts.
7. Support your motorcycle securely and raise the front wheel off the ground using a maintenance stand or a hoist.
8. Loosen the left axle pinch bolts.
9. On the left side, withdraw the front axle shaft, and remove the side collars and wheel.



Installation

1. Attach the side collars to the wheel.
2. On the left side, place the wheel between the fork legs and insert the lightly greased front axle shaft to the end, through the left fork leg and wheel hub.
3. Align the end of the front axle shaft with the surface of the fork leg.



4. Tighten the left axle pinch bolts to hold the axle.
5. Tighten the axle bolt.

Torque: 44 lbf·ft (59 N·m, 6.0 kgf·m).

6. Loosen the left axle pinch bolts.
7. Tighten the right axle pinch bolts.

Torque: 16 lbf·ft (22 N·m, 2.2 kgf·m).

8. Install the right brake caliper and tighten the mounting bolts.

Torque: 23 lbf·ft (31 N·m, 3.2 kgf·m).

9. Install the left brake caliper and tighten the mounting bolts.

Torque: 23 lbf·ft (31 N·m, 3.2 kgf·m).

- Take care to prevent the brake caliper from scratching the wheel during installation.
- Use new mounting bolts when installing the brake caliper.

NOTICE

When installing the brake caliper into position on the fork leg, carefully fit the brake disc between the pads to avoid scratching them.

10. Lower the front wheel on the ground.
11. Apply the brake lever and brake pedal several times. Then, pump the fork several times.

12. Retighten the left axle pinch bolts.

Torque: 16 lbf·ft (22 N·m, 2.2 kgf·m).

13. Raise the front wheel off the ground again, and check that the wheel rotates freely after you release the brake.
14. Remove the protective tape or cloth.

If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.

I Rear Wheel


Removal

1. Support your motorcycle securely and raise the rear wheel off the ground using a maintenance stand or a hoist.


VFR1200XA/XDA

Place your motorcycle on its center stand on a firm level surface.

2. Loosen the muffler band bolt.
3. Remove the muffler stay bolt, nut and washers.



4. Move the muffler outward.
5. Remove the rear wheel nuts, and remove the rear wheel.



Installation

1. To install the rear wheel, reverse the removal procedure.
2. Install the rear wheel and tighten the rear wheel nuts equally.

Torque: 80 lbf·ft (108 N·m, 11 kgf·m).

3. Tighten the muffler band bolt.

Torque: 13 lbf·ft (17 N·m, 1.7 kgf·m).

4. After installing the wheel, apply the brake pedal several times, then recheck the wheel rotates freely. Recheck the wheel if the brake drags or if the wheel does not rotate freely.

If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.

Battery Goes Dead

Charge the battery using a motorcycle battery charger.

Remove the battery from the motorcycle before charging.

Do not use an automobile-type battery charger, as these can overheat a motorcycle battery and cause permanent damage.

If the battery does not recover after recharging, contact your dealer.

NOTICE

Jump starting using an automobile battery is not recommended, as this can damage your motorcycle's electrical system.

Burned-out Light Bulb

Follow the procedure below to replace a burned-out light bulb.

Turn the ignition switch to the OFF or LOCK position.


Allow the bulb to cool before replacing it.

Do not use bulbs other than those specified.

Check the replacement bulb for correct operation before riding.

For the light bulb wattage, see "Specifications." ≥ P. 149

Headlight Bulb




1. Remove the socket cover by turning it counterclockwise.
2. Pull the socket off the bulb without turning it.

3. Press the pin down and pull out the bulb without turning it.
4. Install a new bulb and parts in the reverse order of removal.


Do not touch the glass surface with your fingers. If you touch the bulb with your bare hands, clean it with a cloth moistened with isopropyl (rubbing) alcohol.

Position Light Bulb




1. Pull the socket and remove it.
2. Pull out the bulb without turning.
3. Install a new bulb and parts in the reverse order of removal.

Brake/Tail Light




The brake and tail light uses several LEDs. If there is a LED which is not turned on, see your dealer for servicing.

Front/Rear Turn Signal Light



Front and rear turn signal light uses several LEDs.
If there is a LED which is not turned on, see your dealer for servicing.

License Plate Light





License plate light uses several LEDs.
If there is a LED which is not turned on, see your dealer for servicing.

Blown Fuse

Before handling fuses, see "Inspecting and Replacing Fuses." ≥ P. 67

Fuse Box Fuses



Electrical Trouble u Blown Fuse


1. Remove the seat. 2 P. 78
2. Remove the fuse box cover.
3. Pull the fuses out one by one with the fuse puller in the fuse box cover and check for a blown fuse.

If the main fuse A is blown, see your dealer for servicing.

Always replace a blown fuse with a spare fuse of the same rating.

4. Reinstall the fuse box cover.
5. Reinstall the seat.

I Fuse Holder Fuses



1. Remove the seat. ≥ P. 78
2. Remove the starter magnetic switch cover.

3. Pull the main fuse B and other fuse out one by one with the fuse puller and check for a blown fuse. Always replace a blown fuse with a spare of the same rating.
 - ☐ Spare fuses are provided in the fuse box.
 - ☐ A fuse puller is provided in the fuse box cover.
4. Reinstall parts in the reverse order of removal.

NOTICE

If a fuse fails repeatedly, you likely have an electrical problem. Have your motorcycle inspected by your dealer.

Information

Keys	P. 125
Instruments, Controls, & Other Features ...	P. 126
Caring for Your Motorcycle	P. 127
Storing Your Motorcycle	P. 130
Transporting Your Motorcycle	P. 131
You & the Environment	P. 132
Vehicle Identification Number	P. 133
Emission Control Systems	P. 134
Catalytic Converter	P. 139
Oxygenated Fuels	P. 140
Authorized Manuals	P. 141
Warranty Coverage and Service	P. 142


Honda Contacts	P. 144
USA Reporting Safety Defects	P. 146

Keys

Ignition key

This motorcycle has two ignition keys and a key tag with a key number and a bar code. Store the spare key and the key tag in a safe location. To make a duplicate key, take the spare key and the key tag to your dealer or a locksmith. If you lose all keys and the key tag, the ignition switch assembly will probably have to be removed by your dealer to determine the key number.

A metal key holder may cause damage to the area surrounding the ignition switch.



Instruments, Controls, & Other Features

Ignition Switch

Leaving the ignition switch ON with the engine stopped will drain the battery.

Do not turn the key while riding.

Engine Stop Switch

Do not use the engine stop switch except in an emergency. Doing so when riding will cause the engine to suddenly turn off, making riding unsafe.

If you stop the engine using the engine stop switch, turn the ignition switch off. Failing to do so will drain the battery.

Odometer

The display locks at 999,999 when the read-out exceeds 999,999.

Tripmeter

The tripmeter A and B returns to 0.0 when the read-out exceeds 99,999.9.

Document Bag

The owner's manual, registration, and insurance information can be stored in the plastic document bag on the underside of the seat. \geq P. 54

Ignition Cut-off System

A banking (lean angle) sensor automatically stops the engine and fuel pump if the motorcycle falls over. To reset the sensor, you must turn the ignition switch to OFF and back to the ON position before the engine can be restarted.

Caring for Your Motorcycle

Frequent cleaning and polishing is important to ensure the life of your Honda. A clean motorcycle makes it easier to spot potential problems.

In particular, seawater and salts used to prevent ice on roads promote the formation of corrosion. Always wash your motorcycle thoroughly after riding on coastal or treated roads.

Washing

Allow the engine, muffler, brakes, and other high-temperature parts to cool before washing.

1. Rinse your motorcycle thoroughly using a garden hose to remove loose dirt.
2. If necessary, use a sponge or a soft towel with mild cleaner to remove road grime.
 - Clean the windscreen, headlight lens, panels, and other plastic components with extra care to avoid scratching them.

Avoid directing water into the air cleaner, muffler, and electrical parts.

3. Thoroughly rinse your motorcycle with plenty of clean water and dry with a soft, clean cloth.
4. After the motorcycle dries, lubricate any moving parts.
 - Make sure that no lubricant spills onto the brakes or tires. Brake discs, pads, drum or shoes contaminated with oil will suffer greatly reduced braking effectiveness and can lead to a crash.
5. Apply a coat of wax to prevent corrosion.
 - Avoid products that contain harsh detergents or chemical solvents. These can damage the metal, paint, and plastic on your motorcycle.
Keep the wax clear of the tires and brakes.
 - If your motorcycle has any matte painted parts, do not apply a coat of wax to the matte painted surface.

Washing Precautions

Follow these guidelines when washing:

- Do not use high-pressure washers:
 - ⊣ High-pressure water cleaners can damage moving parts and electrical parts, rendering them inoperable.
 - ⊣ Water in the air intake can be drawn into the throttle body and/or enter the air cleaner.
- Do not direct water at the muffler:
 - ⊣ Water in the muffler can prevent starting and causes rust in the muffler.
- Dry the brakes:
 - ⊣ Water adversely affects braking effectiveness. After washing, apply the brakes intermittently at low speed to help dry them.
- Do not direct water in the under the seat:
 - ⊣ Water in the under seat compartment can damage your documents and other belongings.
- Do not direct water at the air cleaner:
 - ⊣ Water in the air cleaner can prevent the engine from starting.

- Do not direct water near the headlight:
 - ⊣ Any condensation inside the headlight should dissipate after a few minutes of running the engine.
- Do not use waxes containing compounds on matte painted surface:
 - ⊣ Use a soft cloth or sponge, plenty of water, and a mild detergent to clean matte painted surfaces. Dry with a soft clean cloth.

Aluminum Components

Aluminum will corrode from contact with dirt, mud, or road salt. Clean aluminum parts regularly and follow these guidelines to avoid scratches:

- Do not use stiff brushes, steel wool, or cleaners containing abrasives.
- Avoid riding over or scraping against curbs.

Panels

Follow these guidelines to prevent scratches and blemishes:

- Wash gently using a soft sponge and plenty of water.
- To remove stubborn stains, use diluted detergent and rinse thoroughly with plenty of water.
- Avoid getting gasoline, brake fluid, or detergents on the instruments, panels, or headlight.

Windscreen

Using plenty of water, clean the windscreen with a soft cloth or sponge. (Avoid using detergents or any kind of chemical cleaner on the windscreen.) Dry with a soft, clean cloth.

NOTICE

To avoid possible scratching or other damage, use only water and a soft cloth or sponge to clean the windscreen.

For a dirtier windscreen, use a diluted neutral detergent with a sponge and plenty of water. Make sure to wash off all the detergent. (Detergent residue may cause windscreen cracks.)

Replace the windscreen if scratches cannot be removed and they obstruct clear vision. Take care to keep battery electrolyte, brake fluid, or other chemical solvents off the windscreen and screen garnish. They will damage the plastic.

Exhaust Pipe and Muffler

The exhaust pipe and muffler are stainless steel but may become stained by mud or dust.

To remove mud or dust, use a wet sponge and a liquid kitchen abrasive, then rinse well with clean water. Dry with chamois or a soft towel. If necessary, remove heat stains by using a commercially available fine texture compound. Then rinse by the same manner as removing mud or dust.

When the exhaust pipe and muffler are painted, do not use a commercially available abrasive kitchen cleaning compound. Use a neutral detergent to clean the painted surface on the exhaust pipe and muffler. If you are not sure if your exhaust pipe and muffler are painted, contact your dealer.

NOTICE

Even though the exhaust is made of stainless steel, it can become stained. Remove all marks and blemishes as soon as they are noticed.

Storing Your Motorcycle

If you store your motorcycle outdoors, you should consider using a full-body motorcycle cover.

If you won't be riding for an extended period, follow these guidelines:

- Wash your motorcycle and wax all painted surfaces (except matte painted surfaces). Coat chrome pieces with rust-inhibiting oil.
- Place your motorcycle on a maintenance stand and position a block so that both tires are off the ground.
- After rain, remove the body cover and allow the motorcycle to dry.
- Remove the battery (≥ P. 74) to prevent discharge. Charge the battery in a shaded, well-ventilated area.
 - If you leave the battery in place, disconnect the negative - terminal to prevent discharge.

After removing your motorcycle from storage, inspect all maintenance items required by the Maintenance Schedule.

USA For more information about storage, refer to the Honda Winter Storage Guide, available from your dealer.

Canada For more information about storage, visit our website at www.honda.ca and look up “Storage Tips” under the Parts & Service tab.

Transporting Your Motorcycle

If your motorcycle needs to be transported, it should be carried on a motorcycle trailer or a flatbed truck or trailer that has a loading ramp or lifting platform, and motorcycle tie-down straps. Never try to tow your motorcycle with a wheel or wheels on the ground.

NOTICE

Towing your motorcycle can cause serious damage to the transmission.

You & the Environment

Owning and riding a motorcycle can be enjoyable, but you must do your part to protect the environment.

Choose Sensible Cleaners

Use a biodegradable detergent when you wash your motorcycle. Avoid aerosol spray cleaners that contain chlorofluorocarbons (CFCs) which damage the atmosphere's protective ozone layer.

Recycle Wastes

Put oil and other toxic wastes in approved containers and take them to a recycling center. Call your local or state office of public works or environmental services to find a recycling center in your area, and to get instructions on how to dispose of non-recyclable wastes. Do not place used engine oil in the trash, or pour it down a



drain or on the ground. Used oil, gasoline, coolant, and cleaning solvents contain poisons that can hurt refuse workers and contaminate drinking water, lakes, rivers, and oceans.


Vehicle Identification Number

The VIN and engine serial numbers uniquely identify your motorcycle and are required in order to register your motorcycle. They may also be required when ordering replacement parts. The VIN is stamped on the right side of the steering head and also appears on the Safety Certification Label attached to the left side of the frame.

The engine number is stamped on the right rear side of the crankcase.

You should record these numbers and keep them in a safe place.





Emission Control Systems

Your motorcycle engine emits combustion by-products, including carbon monoxide (CO), oxides of nitrogen (NOx), and hydrocarbons (HC). Gasoline evaporation also emits hydrocarbons. Controlling the production of NOx, CO, and HC is important for the environment.


Exhaust Emission Requirements

The U.S. Environmental Protection Agency (EPA) and the California Air Resources Board (CARB), and Environment Canada (EC) require that your motorcycle comply with applicable exhaust, crankcase, and fuel permeation emission standards during its useful life, when operated and maintained according to the instructions provided.

CARB also requires that your motorcycle comply with applicable evaporative emission requirements during its useful life, when operated and maintained according to the instructions provided.

Compliance with the terms of the Distributor's Warranties for Honda motorcycle Emission Control Systems is necessary in order to maintain a valid emissions system warranty (USA only).

The Vehicle Emission Control Information label is located under the seat.



Noise Emission Requirements

The EPA requires that motorcycles built after January 1, 1983 comply with applicable noise emission standards for one year or 3,730 miles (6,000 km) after the time of purchase when operated and maintained according to the instructions provided.

Exhaust Emission Control System

The exhaust emission control system includes the following components that should not need adjustment, although periodic inspection by your dealer is recommended.

PGM-FI System

The PGM-FI (programmed fuel injection) system uses sequential multiport fuel injection, and is comprised of air intake, engine control, fuel control, and exhaust control subsystems.

The engine control module (ECM) uses sensors to determine how much air enters the engine, and then controls how much fuel to inject.

Ignition Timing Control System

The ignition timing control system adjusts the ignition timing to reduce the amount of HC, CO, and NO_x produced.

Secondary Air Injection System

The secondary air injection system adds filtered air into the exhaust gas to help improve emission control performance.

Catalytic Converters

The exhaust system contains one or more catalytic converters. Catalytic converters use a catalyst to convert most of the harmful exhaust gas compounds into harmless compounds.

Evaporative Emission Control System

50 STATE (meets California)

An evaporative emissions control system uses a canister filled with charcoal to adsorb fuel vapor from the fuel tank while the engine is off. The vapor is drawn into the engine and burned while riding.

Crankcase Emissions Control System

The engine is equipped with a closed crankcase system to prevent discharging crankcase emissions into the atmosphere.

Blow-by gas is returned to the combustion chamber through the air cleaner and throttle body.

Fuel Permeation Emission Control

The fuel tank, fuel hoses, and fuel vapor charge hoses use fuel permeation control technologies to prevent fuel vapor emissions.

Tampering with these components to reduce or defeat the effectiveness of the fuel permeation technologies is prohibited.

Noise Emission Control System

TAMPERING WITH THE NOISE CONTROL SYSTEM IS PROHIBITED:

U. S. federal law prohibits, and Canadian provincial laws may prohibit, and Canadian provincial laws may prohibit, the following acts or the causing thereof: (1) The removal or rendering inoperative by any person, other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

AMONG THOSE ACTS PRESUMED TO CONSTITUTE TAMPERING ARE THE FOLLOWING ACTS:

- Removal of, or puncturing the muffler, baffles, header pipes or any other component which conducts exhaust gases.
- Removal of, or puncturing of any part of the intake system.
- Lack of proper maintenance.
- Removing or disabling any emissions compliance component, or replacing any compliance component with a non-compliant component.

Problems Affecting Motorcycle Exhaust Emissions

Have your motorcycle inspected and repaired by your dealer if you experience any of the following symptoms:

- Hard starting or stalling after starting
- Rough idling
- Misfiring or backfiring during acceleration
- Poor engine performance and poor fuel economy

Catalytic Converter

This motorcycle is equipped with a three-way catalytic converter. The catalytic converter contains precious metals that serve as catalysts in high temperature chemical reactions that convert hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NOx) in the exhaust gasses into safe compounds.

A defective catalytic converter contributes to air pollution and can impair your engine's performance. A replacement unit must be an original Honda part or equivalent.

Follow these guidelines to protect your motorcycle's catalytic converter.

- Always use unleaded gasoline. Leaded gasoline will damage the catalytic converter.
- Keep the engine in good running condition. A poorly running engine can cause the catalytic converter to overheat causing damage to the converter or the motorcycle.
- If your engine is misfiring, backfiring, stalling, or otherwise not running properly, stop riding and turn off the engine. Have your motorcycle serviced as soon as possible.

Oxygenated Fuels

Some conventional fuels blended with alcohol or an ether compound are available in some locales to help reduce emissions to meet clean air standards. These gasolines are collectively referred to as oxygenated fuels. If you plan to use oxygenated fuel, check that it is unleaded and meets the minimum octane rating and blend requirement.

The following fuel blends are EPA-approved and have been approved use in your motorcycle:

- Ethanol (ethyl alcohol) up to 10% by volume.
 - ↳ Gasoline containing ethanol may be marketed under the name Gasohol.
- Methanol (methyl alcohol) up to 5% by volume that contain cosolvents and corrosion inhibitors to protect the fuel system. Never use a blend containing more than 5%.

If you accidentally fill your fuel tank with an oxygenated fuel containing higher percentages, you may experience performance problems. To resolve the problem, have your dealer drain the fuel tank and replace with the correct fuel. Fuel system or performance problems resulting from the use of an oxygenated fuel containing higher percentages are not covered by your warranty.

NOTICE

Improper use of oxygenated fuels can damage metal, rubber, and plastic parts of your fuel system. Oxygenated fuel can also damage paint. Damage caused by spilled fuel is not covered by warranty.

If you notice any undesirable operating symptoms or performance problems, try a different brand of gasoline.

Authorized Manuals

The Service Manual used by your authorized dealer is available from your Honda dealer or Helm, Inc. (USA only, Canada: See your Honda dealer to order authorized manuals.)

Also available, but not necessary to service your model, is the Honda Common Service Manual, which explains basic service information for various systems on Honda motorcycles, scooters, and ATV.

The Winter Storage Guide in conjunction with the Owner's Manual and Service Manual can help you prepare your Honda motorcycle, scooter, ATV, and SxS for winter storage.

These Honda manuals are written for the professional technician. However, if you possess the proper tools, observe the safety standards, and are mechanically capable, you should find them easy to use.

Special Honda tools are necessary for some procedures.

Publication Item No.	Description
61MGH00	2016 VFR1200X/XA/XD/XDA Service Manual
61CSM00	Common Service Manual
S9507	Winter Storage Guide
31MGH600	2016 VFR1200X/XA/XD/XDA Owner's Manual

Order On-Line: www.helminc.com

Order Toll Free: 1-888-CYCLE93 (1-888-292-5393)

(NOTE: For Credit Card Orders Only)

Monday – Friday 8:00 AM – 6:00 PM EST

Warranty Coverage and Service

Coverage

Your new Honda is covered by the following warranties:

- Motorcycle Limited Warranty
- Emission Control System Warranty
- Noise Control Warranty (USA only)

The responsibilities, restrictions, and exclusions that apply to these warranties are explained in the Warranties Booklet given to you by your Honda dealer at the time of purchase. Always keep your Honda owner's card with your Warranties Booklet.

Canada Please refer to the Warranty Booklet posted on our web site at www.honda.ca.

It is important to realize that your warranty applies only to defects in material or workmanship of your Honda. Your warranty coverage does not apply to the normal wear and deterioration associated with use of the motorcycle.

Your warranty coverage is not voided if you perform your own maintenance. However, failures that occur due directly to improper maintenance are not covered by these warranties.

You can extend almost all of your warranty coverage through the Honda Protection Plan (USA only). For more information, see your Honda dealer.

Service

Please remember that maintenance recommended in the Maintenance Schedule is not included in your warranty coverage.

If you believe you have a problem with your motorcycle, call the service department of your Honda dealer. Make an appointment for an inspection and diagnosis. You will be asked to authorize that inspection, and your dealer will return the results of the inspection. If a problem exists and is covered under warranty, your dealer will perform the warranty repairs. If you have any questions about your warranty coverage or the nature of the repair, talk to the Service Manager of your Honda dealer.

If a misunderstanding occurs and you aren't satisfied with your dealer's handling of the situation, we suggest you discuss your problem with the appropriate member of the dealership's management team. If you are still not satisfied, contact the owner of the dealership or their designated representative.

Honda Contacts

American Honda Motor Co., Inc.

If you wish to contact Honda directly to comment on your experiences with your motorcycle or with your dealer, please send your comments to the following address:

Motorcycle Division,
American Honda Motor Co., Inc.,
P.O. Box 2200, Torrance,
CA 90509-2200
Mailstop: 100-4C-7B,
Telephone: (866) 784-1870.

Canada

Honda Canada Inc.
Customer Relations Department
180 Honda Boulevard
Markham Ontario L6C 0H9
Telephone: (888) 946-6329
Fax: (877) 939-0909
E-mail: honda_cr@ch.honda.com

Please include the following information in your letter:

- Name, address, and telephone number
- Product model, year, and VIN
- Date of purchase
- Dealer name and address

We will likely ask your Honda dealer to respond, or possibly acknowledge your comments directly.

Your Honda Dealer

The service department of your Honda dealer offers trained personnel to perform regular maintenance and most repairs. It has the latest available service information from Honda and also handles warranty inspections and repairs.

The parts department offers Honda Genuine Parts, Pro Honda products and Honda Genuine Accessories (USA only), and Honda accessories and products (Canada only) that provide the same quality that went into your motorcycle.

The sales department offers the Honda Protection Plan to extend almost all of your warranty coverage (USA only).

Your Honda dealer can also supply information about, riding events, and information about safety training available in your local area, and the Honda Rider's Club of America (USA only).

Honda Rider's Club of America (HRCA)

The Honda Rider's Club of America (HRCA) sponsors local riding chapters at Authorized Honda Dealerships across the country. You can log on to the HRCA Clubhouse website for more information at www.hrca.honda.com.

USA Reporting Safety Defects

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying American Honda Motor Co., Inc.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or American Honda Motor Co., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at: 1-888-327-4236

(TTY: 1-800-424-9153); go to <http://www.safercar.gov>;

or write to:

Administrator, NHTSA,
1200 New Jersey Avenue, SE.,
Washington, DC 20590.

You can also obtain other information about motor vehicle safety from:

<http://www.safercar.gov>.

Specifications

■ Main Components

Type	SC76	
Overall length	90.0 in (2,285 mm)	
Overall width	36.0 in (915 mm)	
	Windscreen position	
Overall height	Low	57.5 in (1460 mm)
	High	60.6 in (1540 mm)
Wheelbase	62.8 in (1595 mm)	
Minimum ground clearance	7.1 in (180 mm)	
Caster angle	28°00'	
Trail	4.2 in (106 mm)	
Curb weight	VFR1200X	608 lb (276 kg)
	VFR1200XD	631 lb (286 kg)
	VFR1200XA	613 lb (278 kg)
	VFR1200XDA	635 lb (288 kg)
Maximum weight capacity*1	397 lb (180 kg)	
Maximum weight on rear carrier	22.0 lb (10 kg)	
Passenger capacity	Rider and 1 passenger	
Minimum turning radius	8.9 ft (2.7 m)	
Displacement	75.5 cu-in (1237 cm ³)	
Bore x stroke	3.19 x 2.36 in (81.0 x 60.0 mm)	

*1 Including rider, passenger, all luggage, and accessories

Compression ratio	12.0:1
Fuel	Unleaded gasoline Recommended: 86 PON or higher
Tank capacity	5.68 US gal (21.5 liters)
Battery	YTZ14S 12V-11.2Ah (10 HR)
	VFR1200X/XA
	1st 2.600
	2nd 1.600
	3rd 1.260
	4th 1.076
	5th 0.961
	6th 0.897
Gear ratios	VFR1200XD/XDA
	1st 2.250
	2nd 1.700
	3rd 1.304
	4th 1.107
	5th 0.967
	6th 0.886
	VFR1200X/XA
Reduction ratios (primary / secondary / final)	1.738 / 1.060 / 2.545
	VFR1200XD/XDA
	1.738 / 1.063 / 2.545

Specifications

Service Data

Tire size	Front	110/80R19M/C 59V
	Rear	150/70R17M/C 69V
Tire type	Radial, tubeless	
Recommended Tires	Front	PIRELLI SCORPION TRAIL E BRIDGESTONE BW-501 RADIAL F
	Rear	PIRELLI SCORPION TRAIL E BRIDGESTONE BW-502 RADIAL F
Tire air pressure	Front	36 psi (250 kPa, 2.50 kgf/cm ²)
	Rear	42 psi (290 kPa, 2.90 kgf/cm ²)
Minimum tread depth	Front	0.06 in (1.5 mm)
	Rear	0.08 in (2.0 mm)
Spark plugs	(standard)	IMR8E-9HES (NGK) or VUH24ES (DENSO)
Spark plug gap	(non-adjustable)	0.031 to 0.035 in (0.80 to 0.90 mm)
Idle speed	1,150 ±100 rpm	
Recommended engine oil	API Service Classification SG or higher except oils labeled as energy conserving or resource conserving on the circular API service label, SAE 10W-30, JASO T 903 standard MA, Pro Honda GN4 4-stroke oil (USA & Canada) or Honda 4-stroke oil, or an equivalent motorcycle oil	

Engine oil capacity	VFR1200X/XA	
	After draining	3.3 US qt (3.1 liters)
	After draining & engine oil filter change	3.5 US qt (3.3 liters)
	After disassembly	4.2 US qt (4.0 liters)
	VFR1200XD/XDA	
	After draining	3.8 US qt (3.6 liters)
Recommended brake fluid	After draining & engine oil filter change	4.1 US qt (3.9 liters)
	After draining, engine & clutch oil filter change	4.2 US qt (4.0 liters)
	After disassembly	5.2 US qt (4.9 liters)
	Honda DOT 4 Brake Fluid	
Recommended final drive oil	Hypoid gear oil SAE 80	
Final drive oil capacity	After draining	6.8 US oz (200 cm ³)
	After disassembly	7.4 US oz (220 cm ³)
Recommended brake (clutch) fluid	Honda DOT 4 Brake Fluid	

	VFR1200X/XA
Cooling system capacity	3.76 US qt (3.56 litres)
	VFR1200XD/XDA
	3.91 US qt (3.70 litres)
Recommended coolant	Pro Honda HP Coolant

■ Bulbs

Headlight	12V-55W x 2
Brake/Tail light	LED
Front turn signal lights	LED
Rear turn signal lights	LED
Position light	12V-5W x 2
License plate light	LED

■ Fuses

Main fuse	A	50A
	B	30A
Other fuses	30A, 20A, 15A, 10A	

■ Torque Specifications

Engine oil drain bolt	21 lbf-ft (29 N-m, 3.0 kgf-m)
Oil filter	19 lbf-ft (26 N-m, 2.7 kgf-m)
Front wheel axle bolt	44 lbf-ft (59 N-m, 6.0 kgf-m)
Front wheel brake caliper mounting bolts	23 lbf-ft (31 N-m, 3.2 kgf-m)
Front wheel axle pinch bolt	16 lbf-ft (22 N-m, 2.2 kgf-m)
Rear wheel nut	80 lbf-ft (108 N-m, 11.0 kgf-m)
Muffler band bolt	13 lbf-ft (17 N-m, 1.7 kgf-m)

Information Record

VIN	
Engine No.	
Color Label & Code	
Owner's Name	
Address	
City/State	
Phone	
Dealer's Name	
Address	
City/State	
Phone	
Service Manager	

- A**
- A/M Switch 37
 - ABS (Anti-lock Brake System)
 - Indicator 30, 106
 - Accessories..... 15
 - Accessory Socket 55
 - Anti-lock Brake System (ABS)..... 11
 - AT Mode..... 46, 48, 49
 - Authorized Manuals..... 141
- B**
- Battery 65, 74
 - Brake Light Switch 90
 - Brakes
 - Fluid..... 69, 87
 - Pad Wear 88
 - Parking Brake..... 89
 - Braking 10
 - Bulb
 - Brake/Tail Light 119
 - Front Turn Signal..... 120
 - Headlight 118
 - License Plate 120
 - Position Light..... 119
 - Rear Turn Signal 120
- C**
- Caring for Your Motorcycle..... 127
 - Catalytic Converter..... 139
 - Clutch
 - Fluid 92
 - Coolant 69, 85
- D**
- D Mode 46, 48, 49
 - Digital Clock Adjustment..... 24
- E**
- Electrical Trouble..... 117
 - Emission Control Systems..... 134
 - Engine
 - Number..... 133
 - Oil 68, 79
 - Oil Filter..... 80, 83
 - Overheats..... 104
 - Starting 42

- Stop Switch 32, 37, 42, 43, 126
Stopping 126
Environment 132
Equipment
Accessory Socket 55
Owner's Manual 126
- F**
Flooded Engine 42
Fuel
Gauge 21
Oxygenated 140
Remaining 21
Fuses 67, 121
- G**
Gasohol 140
- H**
Handle Grip Heater 38
Hazard Switch 32, 36
Headlight Aim 95
Headlight Dimmer Switch 32, 36
- Helmet Holder** 54
High Beam Indicator 31
High Coolant Temperature Indicator 30, 104
Honda Contacts 144
Horn Button 32, 37
- I**
Ignition Cut-off System
Banking Sensor 126
Side Stand 91
Ignition Key 125
Ignition Switch 33, 37, 42, 43
Indicators 30
Information Record 150
Instruments 20
- L**
Labels 7
Load Limits 16
Loading Guidelines 16
Low Oil Pressure Indicator 30

M	
Maintenance	
Fundamentals	62
Importance	57
Safety	58
Schedule	59
Maximum Weight Limit.....	16
Modifications	15
MT Mode	46, 48, 49, 51
N	
Neutral Indicator.....	31
O	
Odometer	126
Oil	
Engine	68, 79
Overheating	104
Oxygenated Fuels	140
P	
Parking	12
Parking brake Indicator.....	30
Parts Location	18
Passing light control switch	32, 36
Petrol.....	53
PGM-FI (Programmed Fuel Injection)	
malfunction indicator lamp (MIL) ..	30, 105
Protective Apparel	9
R	
Recommended	
Coolant.....	69
Fuel	53
Oil	68
Refuelling	53
Removal	
Clip	75
Right Engine Heat Guard	76
Right Under Cowl.....	76
Repair Kit.....	110
Reporting Safety Defects (U.S.)	146
Riding Precautions	10
S	
S Mode	46, 48, 49

Safety Labels.....	7	Puncture.....	110
Safety Precautions.....	9	Replacing.....	70, 110
Shifting Gears.....	44	Torque Control.....	14, 40
Side Stand.....	91	Torque Control Indicator.....	31, 107
Side Stand Ignition Cut-off System.....	91	Torque Control OFF Indicator.....	31
Specifications.....	147	Torque Control Switch.....	37
Speedometer.....	21	Transporting Your Motorcycle.....	131
Start Button.....	32, 37, 42, 43	Tripmeter.....	126
Starting the Engine.....	42	Troubleshooting.....	102
Steering Lock.....	33	Turn signal indicators.....	31
Stopping Engine.....	126		
Storage		V	
Accessory Socket.....	55	Vehicle Identification Number.....	133
Equipment.....	54		
Owner's Manual.....	126	W	
Storing Your Motorcycle.....	130	Warning Indicators on.....	105
Switches.....	32	Warranty Coverage and Service.....	142
		Washing Your Motorcycle.....	127
T		Weight Limit.....	16, 147
Tachometer.....	20	Wheels	
Throttle.....	93	Front removal.....	111
Tires		Rear removal.....	115
Air Pressure.....	70	Windscreen.....	100